



Philips
Portable speaker

FM, Digital tuning

10 one touch presets
USB Direct, Micro SD
Rechargeable battery



AEM120BLU

Digital music on the go

Enjoy listening to music from the Philips all-in-one portable speaker. Play your favorite tunes via USB/ MicroSD card/Aux-in connectivity. The wOOx™ technology speaker is compact and comes with rechargeable battery.

Enjoy music from multiple sources

- Easy playback from USB/MicroSD Card
- FM digital tuning with presets
- Integrated FM Antenna
- AUX-in for easy connection to almost any electronic device

Easy to use

- Stereo headphone jack for better personal music enjoyment
- Compact and mobile
- Built-in rechargeable battery for music playback anywhere

Rich and clear sound

- wOOx™ Loudspeaker Technology for deep and powerful bass
- 1.5W RMS output power

PHILIPS

Portable speaker
FM, Digital tuning 10 one touch presets, USB Direct, Micro SD, Rechargeable battery

Specifications

Audio system

- Output power in total: 1.5W RMS (maximum)
- Sound enhancement: wOOx technology

Audio Playback

- Audio supported format: MP3
- Playback Media: USB flash drive, MicroSD card
- Playback mode: Fast forward and backward, Next/previous track search

Convenience

- Display type: LED display

Connectivity

- Headphone out
- USB charging
- supports microSD card
- Aux in
- USB: USB 2.0 compatible

Tuner/Reception/Transmission

- Tuner bands: FM

Accessories

- USB cable: for charging
- 3.5mm audio cable

Power

- Battery type: Built-in lithium

Packaging dimensions

- Packaging dimensions (W x H x D): 12.8 x 10.3 x 4.1 cm
- Gross weight: 0.279 kg
- Nett weight: 0.253 kg
- Tare weight: 0.026 kg
- Packaging type: Display
- Number of products included: 1
- Type of shelf placement: Laying

Product dimensions

- Product dimensions (W x H x D): 11.8 x 6.7 x 3.1 cm
- Weight: 0.143 kg



AEM120BLU/00

Highlights

USB/MicroSD card

Simply load the USB or MicroSD card with the desired content, plug it into your player - and never have to worry about running out of entertainment choices again.

1.5W RMS output power

This system has 1.5W RMS total output power. RMS refers to Root Mean Square which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

Built-in rechargeable battery



Play music out loud - anytime, anywhere. The built-in rechargeable battery lets you enjoy your personal music without the fuss of entangled power cords and the inconvenient search for an electrical outlet. Enjoy great music with the freedom of portability now.



Issue date 2018-04-24

Version: 1.0.7

12 NC: 8670 001 04875
EAN: 87 12581 69303 9

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com