



Philips
CD Soundmachine with
Dynamic Bass Boost

AZ3021

Compact, digital & personal

A sound reliable classic with a funky look, the AZ3013 delivers what it promises. A portable CD player and digital tuner with Dynamic Bass Boost to blast music with superior bass sounds.

Digital Tuning

- Digital tuning with preset stations for extra convenience
- Multi-functional LCD display

Impressive sound

- Dynamic Bass Boost for deep and dramatic sound

Everything you need

- CD Shuffle/Repeat for personalized music enjoyment
- Compatible with CD-Recordable and CD-ReWritable

PHILIPS

Specifications

Sound

- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2X1.0W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Programmable Tracks: 32

Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Tuner Bands: FM, AM



Convenience

- Display Digits: 6
- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 350 x 192 x 297 mm
- Product dimensions (W x H x D): 294 x 142 x 255 mm
- Weight: 1.9 kg
- Weight incl. Packaging: 2.5 kg

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

Highlights

Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Multi-functional LCD display

Multi-functional LCD display

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.



Issue date 2013-05-10

Version: 1.0.2

12 NC: 9073 101 01367

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com