



Philips  
PhotoFrame

20.3 cm/8" LCD

4:3 frame ratio

8FF3WMI



## Share your memories wirelessly

How many digital photos are hidden on your PC/Mac? We know that everyone has lots! With the Philips Wireless Digital PhotoFrame™ you can enjoy your entire photo collection from your computer - either by wireless streaming mode or transfer mode.

### Enjoy your entire photo collections wirelessly

- Wirelessly stream and display all your photos stored on PC
- Transfer photos wirelessly via easy drag and drop software

### Simple intuitive operation and great convenience

- Two clicks to set up the PhotoFrame wireless connection
- Auto photo orientation to fit portrait or landscape modes
- Have fun with collages: display multiple photos in one view
- Power saving via auto dimming, by detecting ambient lighting

### Top-quality display for print-like pictures

- imagen Pro for sharp, vibrant and natural skin colours
- Add new glow to old memories with RadiantColor
- 4:3 aspect ratio for optimal distortion-free display

**PHILIPS**  
sense and simplicity

# Highlights

## Wi-Fi Protected Setup (WPS)

Using the Wi-Fi Protected Setup is the easiest and most secure way to set up the wireless connection between your wireless PhotoFrame and wireless router. Simply press the WPS button on your wireless router and the WPS button on your PhotoFrame and the setup is complete.

## Wireless Photo Streaming

With a PhotoFrame that supports wireless photo streaming, you don't need to store many photos on the actual PhotoFrame. Instead, all your photos from your home computer or favourite images from the Internet are wirelessly streamed to your PhotoFrame. You can easily browse these images on your PhotoFrame and never worry about the storage capacity of your PhotoFrame.

## PhotoFrame Manager - wireless

PhotoFrame Manager - wireless is photo management software that allows you to view, manage and organise your albums and photos. PhotoFrame Manager runs on Windows XP,

Windows Vista, Mac OS X and is compatible with iPhoto software. The software also transfers your photos wirelessly to your wireless PhotoFrame in a simple to use drag and drop operation - it's really that simple!

## imagen Pro for vibrant colours

The unique Philips imagen enhancement technology automatically analyses your photos to correct colour and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more colour accuracy, colour depth and smart contrast. On top of these, imagen Pro offers enhanced skin colour, sharper images and flicker-free photo viewing which is very important for still pictures.

## Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.

## Multiple-photo collage effect

It's a slideshow effect to show photos in collage form, which automatically and randomly compiles different photos together, eliminating unattractive borders that may result from photos that are smaller than the screen size.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## Smart Power Pro

Smart Power Pro is a sensor that turns PhotoFrame on and off by detecting ambient lighting condition. This reduces energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. The best news is that this is all done automatically!



# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 130° (H)/110° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- Built-in memory capacity: 512 MB (for 2000 photos)
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo
- USB: USB flash drive

## Convenience

- Card Reader: Built in (2 x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels
- Placement: Landscape, Portrait, Photo auto orientation
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Album management: Create, Delete, Edit, Rename
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate
- Photo effects: Radiant colour, Sepia
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Photo source, Slideshow
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Regulatory approvals: CE, GOST, Switzerland, UL/

## cUL

- Other convenience: Kensington lock compatible
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Portuguese
- System compatibility: Mac OS X, Wi-Fi 802.11 b/g network, Windows Vista, Windows XP, with Wi-Fi

## Accessories

- Included accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, CD-ROM with software + manual

## Dimensions

- Set dimensions with stand (W x H x D): 222.6 x 182.2 x 33.2 mm
- Weight: 0.34 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C

## Power

- Power supply: 100-240 VAC, 50/60 Hz
- Power source: DC output 9 V, 2 A
- Power consumption: (System on) 5.09 W

## Packaging dimensions

- Packaging dimensions (W x H x D): 27.8 x 22.9 x 10.7 cm
- Net weight: 0.883 kg
- Gross weight: 1.429 kg
- Tare weight: 0.546 kg
- EAN: 87 12581 41242 5
- Number of products included: 1
- Packaging type: Carton

## Outer Carton

- Outer carton (L x W x H): 29.9 x 24.8 x 24.8 cm
- Net weight: 1.766 kg
- Gross weight: 3.39 kg
- Tare weight: 1.624 kg
- GTIN: 1 87 12581 41242 2
- Number of consumer packages: 2



Issue date 2011-07-13

Version: 4.0.5

12 NC: 8670 000 39025  
EAN: 87 12581 41242 5

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)