

Philips
Classic micro music system



MC146

Obsessed with sound

Relax with great music

Tune in to superb sound from a surprisingly compact design. The Philips classic micro music system will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Dynamic Bass Boost for deep and dramatic sound
- 4 W RMS total output power

Easy to use

- Wake-up and sleep timer functions
- Digital tuning with 20 pre-set stations for extra convenience
- Digital tuning with preset stations for extra convenience

Fits any space, any lifestyle

- Compact design
- Easy-to-use remote control included

PHILIPS

Specifications

Sound

- Output power: 2 x 2 W RMS / 2 x 4 W music power
- Volume control: up/down
- Sound enhancement: Dynamic Bass Boost

Loudspeakers

- Speaker drivers: 3" woofer

Audio playback

- Playback media: CD, CD-R, CD-RW
- Disc playback modes: repeat/shuffle/programme

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Station presets: 20
- Antenna: FM fixed pigtail antenna, MW antenna
- Tuner enhancement: auto digital tuning

Connectivity

- Audio/Video output: Headphone (3.5 mm)
- MP3 Link: 3.5 mm stereo line in

Convenience

- Loader type: top
- Clock: on main display, sleep timer
- Display type: LCD display
- Backlight colour: Blue

Accessories

- Remote control
- Others: FM/MW antenna, User Manual
- Warranty: Worldwide Guarantee booklet

Dimensions

- Gross weight: 5.1 kg
- Main speaker dimensions (W x D): 134 x 152 mm
- Main speaker height: 230 mm
- Main unit depth: 216 mm
- Packaging width: 370 mm
- Main unit height: 233 mm
- Packaging height: 270 mm
- Main unit width: 148 mm
- Packaging depth: 326 mm

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-05-10

Version: 2.0.10

12 NC: 8670 000 35821
EAN: 87 12581 38534 7

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com