



Philips  
PhotoFrame

25.9 cm (10.2") LCD

16:9 frame ratio

10FF3CDW



## Share your memories

Larger screen for more viewing comfort! Display your digital photos in high pixel density quality, perfect digital colour and all the richness of professional prints, on the large screen PhotoFrame.

### Top-quality display for print-like pictures

- High pixel density for sharp and detailed photo display
- imagen Pro for sharp, vibrant and natural skin colours
- Add new glow to old memories with RadiantColor

### Easily display and manage your digital photos

- Create albums and slideshows and manage your photos
- An additional SD card slot for unlimited memories
- Have fun with Collage Pro: automatically or edit things yourself
- Easy drag and drop PC software to transfer your photos

### Simple intuitive operation and great convenience

- Auto photo orientation to fit portrait or landscape modes
- Power saving via auto dimming, by detecting ambient lighting

### Classic design: real materials and fine texture

- Real wood front with fine grain - designed for your home

**PHILIPS**  
sense and simplicity

# Highlights

## Smart Album

Smart Album allows you to create and manage albums, as well as set up and adjust transition effects for your photo slideshows.

## Unlimited memories

Your Philips PhotoFrame comes with an additional SD card slot enabling you to expand the storage space on your PhotoFrame offering plenty of space for all your memories - it's like having virtually unlimited space for your memories and photos! Also thanks to the Philips Memory card manager, you can easily copy and paste images between all your various types of memory cards.

## Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.

## Collage Pro

Remember the fun you had working with your photos in the past - such as cutting them and creating nice collections! Collage Pro is a unique and advanced feature provided by Philips digital PhotoFrame. Just like on other Philips digital PhotoFrames with Collage function, you can run collage slideshows automatically (random view). With Collage

Pro, you can also edit and create collages yourself. You can also easily create a collage from multiples sources such as an SD card or USB pen drive.

## High Pixel Density Display

The very best high-density screen shows off your treasured photos with the same 'real life' rich detail and vibrant colours as high-quality prints.

## imagen Pro for vibrant colours

The unique Philips imagen enhancement technology automatically analyses your photos to correct colour and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more colour accuracy, colour depth and smart contrast. On top of these, imagen Pro offers enhanced skin colour, sharper images and flicker-free photo viewing which is very important for still pictures.

## PhotoFrame Manager

You can easily connect your Philips PhotoFrame to your computer via a USB cable. The PhotoFrame Manager is a simple to use drag and drop software tool that allows you to simply drag your photos from your computer to your PhotoFrame - it's really that simple!

On top of this, the software enables simple editing like zoom and crop. You can even preview what you have edited before transferring to your PhotoFrame.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## Real wood with fine grain

There are plenty of digital photo frames on the market with ugly, gadget-type designs. They won't fit my home interior at all. Now, Philips comes with a PhotoFrame with a real wood front in a dark espresso colour and fine grain which perfectly fits the simple and clean rear cover design. It not only suits your home decor but brightens up any room!

## Smart Power Pro

Smart Power Pro is a sensor that turns PhotoFrame on and off by detecting ambient lighting condition. This reduces energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. The best news is that this is all done automatically!



# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 120° (H)/110° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 16:9
- Panel resolution: 800 x 480
- Brightness: 250 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1

## Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

## Storage Media

- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo
- Built-in memory capacity: 128 MB (for 510-1020 photos, around 26 MB used by system)
- USB: USB flash drive

## Convenience

- Card Reader: Built-in (3 x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels
- Placement: Landscape, Photo auto orientation, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Photo effects: Black and White, Frames, Sepia, Radiant colour
- Slideshow management: Create slideshow, Delete slideshow, Rename slideshow
- Slideshow setting: Collage (multiple pictures), Random, Sequential, Transition effect
- Screen background: Black, Grey, White, Auto-fit
- Setup function: Beep on/off, Brightness adjustment, Clock display enable/disable, Event reminder with snooze, Language, Photo source, Set time and date, Status, Auto on/off, Slideshow
- System status: Firmware version, Remaining memory

- Connected media status: Connected media, Remaining memory
- Plug and Play Compatibility: Mac OS X, Windows 2000/XP or later, Windows Vista
- Regulatory approvals: BSMI, CCC, CE, C-Tick, FCC, GOST, PSB, Switzerland, UL/cUL
- Other convenience: Kensington lock compatible
- On-Screen Display languages: Danish, Dutch, English, French, German, Italian, Russian, Simplified Chinese, Spanish

## Accessories

- Included accessories: AC-DC Adapter, Quick start guide, USB cable, CD-ROM with software + manual, Stand

## Dimensions

- Set dimensions with stand (W x H x D): 284.6 x 195.1 x 35.4 mm
- Weight: 0.718 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -10°C to 60°C

## Power

- Power consumption: (System on 5.43 W)
- Power mode supported: AC powered

## Outer Carton

- GTIN: 1 87 12581 41258 3
- Number of consumer packages: 2
- Gross weight: 4.1738 kg
- Outer carton (L x W x H): 36.1 x 26.3 x 25.4 cm
- Net weight: 2.0748 kg
- Tare weight: 2.099 kg

## Packaging dimensions

- EAN: 87 12581 41258 6
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 34 x 24.2 x 10.9 cm
- Gross weight: 1.774 kg
- Net weight: 1.0374 kg
- Tare weight: 0.7366 kg



Issue date 2012-05-11

Version: 2.1.7

12 NC: 8670 000 39047  
EAN: 87 12581 41258 6

© 2012 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)