

Philips Harmony
Component micro Hi-Fi
system

Hi-Fi dome tweeter
CD, USB, FM
60W, 4 Hi-Fi drivers

Harmony





# Enjoy high fidelity music

# Obsessed with sound

Great sound from CDs, MP3 Link and USB Direct with this Philips MCM7000/12. Hi-Fi dome tweeters bring you detailed and natural sound while Treble and Bass Control lets you adjust tones. Add on a high quality look with an aluminum cabinet.

## **Enrich your sound experience**

- Hi-Fi dome tweeter for detailed and natural sound
- Class 'D' digital amplifier for quality sound performance
- Treble and Bass Control for easy high and low tone settings
- Gold-plated speaker connector for finest signal transmission
- 60W RMS total output power

## Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback

## Premium finishing with noble materials

· Aluminum cabinet for quality look and feel



# **Highlights**

### **Treble and Bass Control**

Treble and bass are equalizer features that control the high and low frequency sound levels of your audio respectively. Treble specifically regulates the amplification of the high tones in the music while bass controls the amplification level of the low tones. Using the up and down keys, the listener can conveniently place more or less emphasis on the low and high tones, or leave treble and bass flat to playback music according to its original recorded setting. Treble and Bass Control lets you listen to your music the way you like it.

### **MP3 Link**



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

### **USB Direct**



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and
















### Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

### Gold-plated speaker connector



The Gold-plated speaker connector ensures better audio signal transmission compared to traditional click-fit connections. It also minimizes the electrical signal loss from the amplifier to the speaker box, resulting in sound reproduction that's as close to reality as possible.

# Specifications

- Output power (RMS): 2 x 30 W
- · Sound Enhancement: Treble and Bass Control, Loudness, Class "D" Digital Amplifier

### Loudspeakers

- Loudspeaker types: Dome tweeter
  Main Speaker: 5" woofer, 2 way, Bass Reflex Speaker System, Speaker grilles detachable
- · Loudspeaker enhancement: gold-plate speaker connectors

### Audio playback

- Disc playback modes: repeat/shuffle/program, fast forward/backward, next/previous album search, next/previous track search
- USB Direct playback modes: play/pause, fast backward/fast forward, previous/next, program play, repeat, shuffle, stop
- Playback media: CD, CD-R/RW, MP3-CD, WMA-CD, USB flash drive
- Others: ID3-tag support

### Tuner/Reception/Transmission

- Station presets: 20
- RDS: station name, program type, radio text, RDS
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: Easy set (plug & play), auto digital tuning, auto scan
- Tuner bands: FM mono, FM stereo

### **Connectivity**

- Front / Side connections: USB 2.0
- MP3 Link: 3.5mm stereo line in
- Headphone: 3.5 mm
- Rear Connections: AUX in, Line out, FM Antenna, Left and right speakers

### **Convenience**

- · Alarms: CD Alarm, Radio Alarm, USB alarm
- · Clock: On main display
- Display Type: VFD display
- Indications: DIM mode

### Accessories

- · Included accessories: AC Power Cord, FM antenna, 3.5mm stereo line in cable, Warranty certificate
- Remote control: 44-key remote with 2xAAA batteries
- · User Manual: 16 languages

### **Dimensions**

- Main unit width: 250 mm
- Main unit height: 92 mm
- · Main unit depth: 285 mm
- Main speaker dimensions (W x D): 174 x 240 mm
- Main speaker height: 260 mm
- Packaging width: 425 mm
- Packaging height: 441 mm
- Packaging depth: 310 mm
- Gross weight: 10 kg
- Net weight: 8.5 kg

• Power supply: 220-240V, 50Hz



Issue date 2014-06-13

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 2.1.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 71442 EAN: 87 12581 57915 9

www.philips.com