



Philips  
DVD Player

Karaoke

DVP642K



## You have it, we play it!

Dreaming of a player that plays practically any disc format while enjoying flawless, true-to-life picture quality? Now you can! With Philips DVD players, indulge in great movie and music entertainment experience delivered right to your home

### Superb audio and video performance

- PAL & NTSC Progressive Scan gives razor-sharp images
- 4x video upsampling for improved image quality
- 192kHz/24 bit audio DAC enhances analogue sound input
- Built-in decoders for Dolby Digital and DTS

### Plays practically any disc format

- Movies: DVD, DVD+R/RW, (S)VCD, DivX, MPEG4
- Music: CD, CD-R/RW and MP3-CD
- Picture CD (JPEG) with music (MP3) playback

### Ultimate convenience

- Smart Picture provides personalized image settings

### Your personal karaoke show

- Karaoke for endless karaoke entertainment at home

**PHILIPS**  
sense and simplicity

## Specifications

### Picture/Display

- **Aspect ratio:** 4:3, 16:9
- **Picture enhancement:** 4x Video Upsampling, Progressive Scan, Smart Picture

### Sound

- **Crosstalk (1kHz):** 124dB dB
- **D/A converter:** 192KHz/24 bit
- **Distortion and Noise (1kHz):** 92dB dB
- **Dynamic Range (1kHz):** 94dB dB
- **Signal to noise ratio:** 110dB
- **Sound Enhancement:** Smart Sound
- **Sound System:** Dolby Digital (AC-3), MPEG2, Stereo

### Video Playback

- **Compression formats:** Divx 3.11, Divx 4, Divx 5, MPEG1, MPEG2, MPEG4
- **Playback Media:** CD, CD-R, CD-RW, DivX, DVD+RW, DVD+R, DVD-RW (Video mode), DVD-R, DVD-Video, MP3-CD, MPEG4, Picture CD, SVCD, Video CD
- **Disc Playback Modes:** A-B Repeat, Disc Menu, Fast Backward, Fast Forward, OSD, Pause, Screen Saver, Standard Play, Zoom

## Product highlights

### PAL & NTSC Progressive Scan

*Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending fields with the odd lines to the screen first, followed by the fields with the even lines, both fields are written at one time. A flicker-free high resolution image is created giving you the best viewing experience.*

### Video Upsampling

*Video Upsampling is a technology that decreases distortion to dramatically improve picture quality. Increasing the video processing to 54MHz or even 108MHz, is in effect converting the video to 8:8:8\* (54MHz) or 16:16:16 (108MHz) format which has about 4 to 8 time more horizontal resolution bandwidth than in standard DVD format. This processing reduces the MPEG "mosquito net" distortion dramatically resulting in picture quality that is pure and distortion free.*

### 192kHz/24 bit audio DAC

*192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.*

### Built-in DD and DTS decoders

*A Built-in Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism.*

### Multi-format Movies-DivX, MP4

*Multi-format playability allows you to play most disc formats for maximum compatibility and viewing pleasure.*

### Multi-format Music

*Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.*

### Picture CD with MP3 Playback

*Picture CD is a CD-R or CD-RW disc on which you can store your MP3 and digital pictures. When inserting a Picture CD in the DVD player, a screen menu will pop up, showing your JPEG's and/or MP3 files on the disc. Just select the music and pictures files you wish to enjoy and press play or OK. You can watch your pictures on TV with your music playing simultaneously.*

### Smart Picture

*Smart Picture provides the optimum picture settings for color, brightness, saturation, contrast, sharpness, and so on, to enhance your overall viewing experience at all times.*

### Karaoke

*The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.*



Date of issue 2007-01-15

Version: 1.0

12 NC: 8622 810 11574  
EAN: 87 10895 79828 0

© 2007 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)