

# PHILIPS



## Wireless TV headphones

Clear sound from 30 mm drivers

Lightweight headband

Up to 18 hours play time

Great passive noise isolation



TAH6005BK

## Great sound for shows, films and more

Let the sound of your favourite shows and films flow, without disturbing anyone else! These wireless over-ear TV headphones give you clear, latency-free sound with great bass. The wireless range is an impressive 100 m.

### Wherever you love to sit

- 100 m wireless range. Listen anywhere in your home
- 18 hours play time from a full charge
- 2 rechargeable AAA batteries. 6 hours charging time

### Hear it all

- Every film, every show. Listen without disturbing others
- 30 mm neodymium drivers. Clear sound with great bass
- Over-ear fit. Great passive noise isolation
- Auto-tuned FM wireless connection

### Long listening comfort

- Lightweight and comfortable
- Cushioned, adjustable headband
- Adjustable ear cups

# Specifications

## Sound

Frequency range: 20–20,000 Hz  
Speaker diameter: 30 mm  
Impedance: 24 Ohm  
Maximum power input: 20 mW  
Sensitivity: 115 dB (1k Hz)  
Distortion (THD): <1%; 1% THD at 1 KHz  
Driver type: Dynamic

## Connectivity

Wireless  
Detachable cable  
Maximum range: Up to 100 m  
Type of wireless transmission: FM  
Channel selection: Automatic  
Headphone socket: 3.5 mm

## Outer Carton

Length: 32.5 cm  
Number of consumer packages: 3  
Width: 26 cm  
Gross weight: 3.314 kg  
Height: 32.5 cm  
GTIN: 1 48 95229 11122 3  
Net weight: 1.794 kg  
Tare weight: 1.52 kg

## Convenience

Volume control  
Type of controls: Button

## Power

Rechargeable  
Number of batteries: 2 pcs  
Music play time: 18 hour(s)  
Charging time: 6 hour(s)

Battery weight (Total): 23.36 g  
Battery capacity (Headphones): 700 mAh  
Battery type (Headphones): Rechargeable NiMH

## Packaging dimensions

Height: 31.3 cm  
Packaging type: Box  
Type of shelf placement: Hanging  
Width: 24 cm  
Depth: 10 cm  
Number of products included: 1  
EAN: 48 95229 11122 6  
Gross weight: 0.926 kg  
Net weight: 0.598 kg  
Tare weight: 0.328 kg

## Product dimensions

Height: 20 cm  
Width: 19 cm  
Depth: 8 cm  
Weight: 0.207 kg

## Accessories

Others: 2 x AAA rechargeable batteries  
Audio cable: 3.5 mm TV cable  
Quick Start Guide  
Docking station (connector): 3.5 mm  
Docking station (transmitter)  
Included adapters: Charge adapter

## Design

Colour: Black  
Wearing style: Headband  
Ear coupling material: Synthetic leather  
Ear fitting: Over-ear  
Earcup type: Closed-back

# Highlights

## Always clear sound

Perfectly tuned 30 mm drivers give clear, sparkling sound with great bass — perfect for everything you love to watch. The full-size ear cups have an over-ear fit for great passive noise isolation. You won't miss a line of dialogue and you won't disturb others.

## Auto-tuned FM wireless connect

These wireless TV headphones automatically select the best available FM connection, giving you crystal-clear sound with no latency. You won't have to adjust anything and with a 100 m range you can easily listen anywhere in your home.

## Lightweight and comfortable

The lightweight design is super-comfortable — perfect if you're bingeing a late-night series and don't want to wake the baby! The cushioned headband and ear cups are adjustable, making it easy to find the best fit for you.

## 18 hours play time

The included pair of rechargeable AAA batteries gives you up to 18 hours play time from a single charge. Charging takes 6 hours.

