



AJ260

## Personal weather forecaster

with wireless outdoor temperature sensor

Start your day right - every day! The compact AJ260 features an radio controlled clock and graphical weather forecast icons with multi-color light indicators. Your trusty weather forecaster also keeps you punctual - always.

### **Stylish design with all the functions you need**

- Display weather forecast with graphical animations
- Multi-color light weather indicator
- Temperature display for both indoor and outdoor temperature
- Built-in hygrometer displays indoor humidity
- Digital tuning with preset stations for extra convenience

### **Start the day your way**

- Wake up to your favorite radio tune or a buzzer
- Gentle wake for a pleasant wake up experience
- Dual alarm time

### **Keep you punctual - always**

- Digital radio-controlled clock for accurate time settings
- Large backlit LCD display for easy viewing in low light

**PHILIPS**  
sense and simplicity

# Highlights

## Radio-controlled clock

Radio-controlled clock automatically synchronizes with the local radio broadcast's standard time so you don't ever need to worry about checking for accuracy or making adjustments. Accurate time without latency is ensured daily or while the clock's power is on. Rest assured you'll always be punctual for every appointment!

## Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to

memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Gentle wake

Start your day right by waking up gently to a gradually escalating alarm volume. Normal alarm sounds with a preset volume are either too low to wake you up or are so uncomfortably loud that you are rudely jolted awake. Choose to wake up to your favorite

music, radio station or buzzer alarm. Gentle wake's alarm volume gradually increases from subtly low to reasonably high in order to gently rouse you.

## Large backlit LCD display

Backlit LCD display ensures easy viewing and operation in low light conditions, and provides clear information at a glance.



**DIGITAL  
TUNER**



# Specifications

## Weather Forecast

- Status: Sunny, Cloudy, Partly cloudy, Rainy, Stormy, Snow
- Light indicator: Amber (Sunny), Blue (Cloudy), Light blue (Partly cloudy), Purple (Rainy), Red (Stormy), White (Snow)

## Indoor Thermometer

- Temperature range: -20°C to 70 °C
- Temperature resolution: 0.1 °C

## Outdoor Thermometer

- Wireless transmission: 50 meter (Open area)
- RF transmission frequency: 433 MHz
- Temperature range: -20°C to 70 °C
- Temperature resolution: 0.1 °C

## Indoor Hygrometer

- Relative humidity range: 20% to 90% RH
- Humidity resolution: 1 %RH

## Tuner/Reception/Transmission

- Tuner Bands: FM
- Auto digital tuning
- Station presets: 10

## Convenience

- Radio controlled clock: Synchro time with the radio signal MSF60 generated from Rugby, England
- Alarms: Dual alarm time, 24 hour alarm reset, Radio Alarm, Buzzer Alarm, Gentle Wake, Repeat

- alarm (snooze), Sleep timer
- Backlight
- Backlight color: White
- Clock/Version: Digital
- Display Enhancements: Brightness Control
- Display Type: LCD

## Sound

- Output power (RMS): 80mW
- Sound System: Mono
- Speaker diameter: 2.5"
- Volume Control: rotary

## Accessories

- Included accessories: User Manual, Warranty certificate, AC-DC Adapter

## Dimensions

- Packaging dimensions (W x H x D): 288 x 140 x 80 mm
- Product dimensions (W x H x D): 169 x 105 x 43 mm
- Weight: 0.4 kg
- Weight incl. Packaging: 0.55 kg

## Power

- Battery type: AAA / LR03 Alkaline
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 4



Issue date 2011-07-01

Version: 2.0.10

12 NC: 8670 000 31336  
EAN: 87 12581 34445 0

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)