

Philips  
DVD player



DVP4080

## Small on space, big on picture quality

Be in total empowerment to enjoy sharp, crystal-clear picture and sound quality movies and music wherever and whenever you desire. It's your home entertainment - at your control.

### **Bring audio and video to life**

- High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality
- Smart Sound optimizes audio settings

### **Play all your movies and music**

- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays MP3, WMA and JPEG digital camera photos

### **Fits any space, any lifestyle**

- Compact design that fits anywhere

# PHILIPS

# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling, 3/2 - 2/2 motion pull down

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD-R/CD-RW, CD, DVD, DVD-R/-RW, DVD+R/+RW, Video CD/SVCD
- Compression formats: MPEG1, MPEG2
- Video disc playback system: PAL, NTSC

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW
- MP3 bit rates: 32 - 256 kbps
- Compression format: MP3, WMA, PCM, Dolby Digital

## Still Picture Playback

- Playback Media: DVD-R/-RW, DVD+R/+RW, CD-

- R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Rotate, Zoom, Slideshow, Flip photos

## Connectivity

- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, ComponentVideo out Progressive

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Malay, Korean, Simplified Chinese, Thai, Traditional Chinese

## Power

- Power consumption: < 10 W
- Power supply: 110-240V, 50/60 Hz
- Standby power consumption: < 0.8 W

## Accessories

- Included accessories: 2 x AAA Batteries, Audio/Video cable, Remote Control, World Wide Warranty leaflet, Power cord, User Manual

## Dimensions

- Set dimensions (W x H x D): 226 x 48 x 209 mm

# Highlights

## Plays it all


Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theater system - in the comfort of your living room.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Smart Sound

Smart Sound provides the optimal sound settings for ultra bass, bass, treble and balance so that you can get the best entertainment experience.



Issue date 2014-02-10

Version: 1.1.7

12 NC: 8670 000 28506  
EAN: 87 12581 32591 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)