



Philips
Micro music system

DAB+
CD, MP3-CD, USB, FM
20W max



BTB2315

Relax to great music

Obsessed with sound

Lose yourself in music, streamed over Bluetooth, on a CD or even USB direct. Then tune in to your favorite radio shows with DAB+ and FM compatibility. This Philips micro system brings you everything, with 20W of maximum output power.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control
- 20W RMS maximum output power

Enjoy your music from multiple sources

- Stream music wirelessly via Bluetooth™ from your smartphone
- DAB+ and FM compatible for a complete radio experience
- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback
- Audio-in for portable music playback

Easy to use

- Motorized CD loader for convenience access
- Digital tuning with preset stations for extra convenience

PHILIPS

Micro music system
DAB+ CD, MP3-CD, USB, FM, 20W max

Highlights

Stream music via Bluetooth™



Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can enjoy your favorite music, sound from video or game wireless on this speaker easily.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a

bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

BTB2315/12

USB Direct for easy MP3 music




Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set balanced, clear, powerful, warm and bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

DAB+ and FM compatible

DAB+ and FM compatible for a complete radio experience



Specifications

Sound

- Sound enhancement: digital sound control
- Maximum output power (RMS): 20W

Loudspeakers

- Speaker drivers: 3" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Bluetooth: Play/Pause, Previous/Next

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan
- DAB/DAB+: Info display, Smart scan

Connectivity

- USB: USB host
- Audio in (3.5mm)

- Bluetooth
- Bluetooth profiles: A2DP, AVRCP

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LED display
- Loader type: tray

Accessories

- Included accessories: AC Power Cord, FM antenna, User Manual, DAB antenna
- Remote control: 21-key remote

Dimensions

- Main unit width: 180 mm
- Main unit height: 121 mm
- Main unit depth: 247 mm
- Main speaker dimensions (W x D): 150 x 125 mm
- Main speaker height: 238 mm
- Packaging width: 577 mm
- Packaging height: 312 mm
- Packaging depth: 185 mm
- Gross weight: 4.5 kg
- Net weight: 3.55 kg

Power

- Power supply: 220-240V, 50Hz



Issue date 2016-05-10

Version: 1.0.4

12 NC: 8670 001 21012
EAN: 48 95185 60483 1

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com