

Philips  
Classic micro sound  
system

• Dock for iPod/iPhone



DCM186



## Obsessed with sound

Relax to great music

Connect to power - and rich sound - when you dock and charge your iPod/iPhone on this Philips Micro system. Dynamic Bass Boost will tantalise your ears while its stylish, compact design will enhance any space and entice your senses.

### Enjoy your music from multiple sources

- Play and charge your iPod/iPhone simultaneously
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

### Enrich your sound experience

- 15 W RMS total output power
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings

### Easy to use

- Dock any iPod/iPhone, even in its case
- Single remote control for the system and iPod
- Wake-up and sleep timer functions

# PHILIPS

# Specifications

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Fast Forward/Reverse, Next/Previous Track Search, Shuffle Play, Repeat Play
- Loader Type: Top
- Cradle playback mode: Fast forward and reverse, Next and Previous track, Play and Pause, Charging iPhone, Charging iPod

## Sound

- Output Power: 15 W RMS total power
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Sound System: Stereo

## Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

## Connectivity

- Other connections: FM fixed pigtail antenna
- Audio Connections: 3.5 mm stereo line in -MP3 link

## Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm

- Clock: On main display
- Display Type: LCD
- Backlight colour: Blue
- Backlight

## Accessories

- Included accessories: World Wide Warranty leaflet
- Quick start guide: English
- User Manual: English

## Dimensions

- Set dimensions (W x H x D): 148 x 233 x 232 mm
- Main speaker dimensions (W x H x D): 132 x 233 x 159 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 5.1 kg

## Power

- Power supply: 220-240 V, 50 Hz

## iPod compatibility

- Compatible with: iPod mini, iPod nano, iPod with colour display, iPod 5th Generation, iPod classic, iPod, iPod 1G, iPod 6th Generation, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod touch, iPod touch 2nd Gen 8/16/32 GB

## iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

# Highlights

## Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adapters. What's more, it works even when most protective cases are on - just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.



Issue date 2013-05-29

Version: 1.1.3

12 NC: 8670 000 72105  
EAN: 87 12581 58274 6

© 2013 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)