

Philips
MP3 Mini Hi-Fi System

420W

3-disc changer
Multisource ripping

FWM592



Obsessed with sound

Get ready for a non-stop party. The Philips Mini hi-fi system will let you enjoy ripped music files from your hi-fi system with your friends. Ultimate powerful bass and virtual surround sound, life's just a big, continuous concert.

Multiple source MP3 music

- Compatible with WMA and MP3 CDs
- MP3 Link for portable music playback
- Rip music from CDs, radio and karaoke onto USB device
- Play back songs from USB device

Powerful sound you can hear and feel

- MAX Sound for instant power boost
- Dual amplifier for better sound performance
- 420W RMS total output power
- Digital Sound Control for optimized music style settings

Easy to use

- Clock, alarm and sleep timer
- Connection for TV or DVD player

Be a singing sensation

- Karaoke for endless singing entertainment

PHILIPS

Highlights

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Rip music onto USB device

Rip music from CDs, radio and karaoke onto USB device



Specifications

Sound

- Total Sound Power (RMS): 420 W
- Output power: 4 x 105 W / ch RMS, 5200 W PMPO
- Sound enhancement: MAX sound, incredible surround, Dynamic Bass Boost 3 steps, digital sound control 4 modes, virtual ambience control

Loudspeakers

- Number of speaker boxes: 2
- Speaker drivers: 6.5" woofer
- Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/one/all/program, repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, repeat, shuffle, stop

Audio recording

- Recording media: USB device
- USB recording modes: instant record, programmed tracks, schedule radio program, single disc, single track
- USB recording sources: CD, tuner, microphone in, AUX

Tuner/Reception/Transmission

- Station presets: 40
- Tuner bands: FM, MW
- Antenna: FM antenna, MW antenna
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug & play)

Connectivity

- Aux in: 2xRCA (Audio)
- USB: USB host
- MP3 Link: 3.5mm stereo line in
- Microphone: dual microphone sockets

Convenience

- Alarms: CD alarm, radio alarm, USB alarm
- Number of discs: 3
- Clock: on main display, sleep timer
- Loader type: 3 CD carousel
- Display enhancements: DIM mode
- Display type: VFD display
- Karaoke: MIC volume, echo control

Accessories

- Remote control: 36-key with 2xAAA batteries
- Cables/Connection: *Flat pin adaptor, MP3 Link cable
- User Manual: B-Portuguese, Spanish
- Others: batteries for remote control, FM/MW antenna, Quick start guide
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 19.3 kg
- Main unit depth: 382 mm
- Main unit height: 345 mm
- Main unit width: 265 mm
- Speaker height: 344 mm
- Speaker depth: 271 mm
- Packaging width: 1030 mm
- Packaging height: 420 mm
- Packaging depth: 320 mm
- Speaker weight: 249 mm

Power

- Power supply: 100 - 240V AC, 50/60Hz



Issue date 2014-02-05

Version: 3.0.6

12 NC: 8670 000 36161
EAN: 87 12581 38791 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com