



Philips
PhotoFrame

17.8 cm (7") LCD

16:9 frame ratio

7FF3FPB



Share your memories

How many digital pictures are hidden on your PC? See, share, organize and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

Top quality display for print-like pictures

- imagen for sharp and vibrant color
- Add new glow to old memories with RadiantColor
- SmartContrast: For incredible rich black details

Easily display and manage your digital photos

- Have fun with collages: display mutiple photos in one view
- View USB flash drive photos without a PC

Simple intuitive operation and great convenience

- Intuitive UI, 5-way-keypad for easy navigation and operation
- Auto photo orientation to fit portrait or landscape modes

Green design

- Auto on/off display at pre-set times for power saving

Stylish and curve design complements your photos

- Tasteful glossy finishing and great touch feeling

PHILIPS
sense and simplicity

Highlights

imagen technology

imagen is exclusive Philips photo enhancement technology that automatically analyzes your photos to correct color and adjust for optimal contrast: imagen separates colors to avoid "crosstalk" adjusts brightness distribution for great visual contrast and corrects Gamma for color accuracy.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

SmartContrast

SmartContrast is a Philips technology that analyzes the contents you are displaying, automatically adjusting colors and controlling backlight intensity to dynamically enhance contrast for the best digital images and videos or when playing games where dark hues are displayed. When Economy mode is selected, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than the screen size.

Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on USB flash drive.

Auto on/off display

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.



Imagen



RadiantColor



Collage



USBConnectivity



SmartPower



SmartContrast



MEMORY CARD SLOT



Lead Free!

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Brightness: 200 cd/m²
- Aspect ratio: 16:9
- Panel resolution: 480 x 234
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro

Convenience

- Card Reader: Built-in (2x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Sepia, Radiant color
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Gray, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory

- Plug & Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

Accessories

- Included accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, User Manual

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power consumption: 5 W
- Power mode supported: AC powered

Packaging dimensions

- EAN: 87 12581 41217 3
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 26.1 x 22.2 x 7.8 cm
- Nett weight: 0.604 kg
- Gross weight: 0.793 kg
- Tare weight: 0.189 kg

Outer Carton

- GTIN: 1 87 12581 41217 0
- Number of consumer packagings: 2
- Outer carton (L x W x H): 28.3 x 24.3 x 18.8 cm
- Nett weight: 1.208 kg
- Gross weight: 1.988 kg
- Tare weight: 0.78 kg



Issue date 2013-01-31

Version: 4.0.14

12 NC: 8670 000 38992
EAN: 87 12581 41217 3

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com