



#### Wall charger

- USB A & USB C charging ports
- Power Delivery
- QC 4+
- PPS

DLP2682CW/00

## Wall charger with 2 USB-C and USB-A port

65W with QC 4+ and PD 3.0

Charge your laptop and latest devices from USB-C port. Support PD3.0 and QC 4+ charging modules to minimize the charging time. USB-A port charging your other devices simultaneously. Available with detachable EU, UK, AU plugs.

### Benefits

#### Superior Charging Design

- Smart protection against overheat, overvoltage & overcurrent
- Wall charger with GaN technology
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)

#### Top Performance

- USB-C port with Power Delivery support

### Features

#### USB-C port with PD

USB-C is the latest charging connector standard, which is now adopted by mobile devices such as cell phones, cameras and tablets. PD (Power delivery) is the USB standard for power delivery for more power and fast charging.

#### Smart Protection

Smart protection against overheating, overvoltage and overcurrent

**PHILIPS**

### Charger with GaN technology

Wall chargers that adopt GaN (Gallium Nitride) technology will use less electrical components with better heat performance. The compact chargers can provide more power with faster charging times. The increased power are capable to power deliver to modern laptops with USB-C connection.

### 50% charge in 30 min

Fast charging - Charge your mobile phone empty to 50% in 30 minutes time.

## Specifications

[field not found 'disclaimer\_text']

### Packaging dimensions

Packaging type	Box
Number of products included	1
Height	12.8 cm
Width	7.8 cm
Depth	5.1 cm
Height	5.0 inch
Width	3.1 inch
Depth	2.0 inch
Gross weight	0.215 kg
Nett weight	0.185 kg
Tare weight	0.030 kg
Gross weight	0.474 lb
Nett weight	0.408 lb
Tare weight	0.066 lb
EAN	48 95229 13265 8

### Outer Carton

Number of consumer packagings	36
Length	34.3 cm
Width	25.3 cm
Height	35.5 cm
Length	13.5 inch
Width	10.0 inch
Height	14.0 inch
Gross weight	8.99 kg
Nett weight	6.660 kg
Tare weight	2.330 kg
Gross weight	19.819 lb
Nett weight	14.683 lb
Tare weight	5.136 lb
GTIN	1 48 95229 13265 5

### Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real-time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

### Power

Adaptor type Output	Detachable with UK EU AU socket 65W( Max) [USB type-C1: 3.3V-20V/3A;5V/3A;9V/3A;12V/3A 15V/3A;20V/3.25A(65W Max) USB type-C2: 3.3V-20V/3A;5V/3A;9V/3A; 12V/3A 15V/3A;20V/3.25A(65W Max) USB-A: 3-10V/3A;5V/3A;9V/3A; 12V-2.5A 15V/2A;20V/1.5A(30W Max) USB-C1+USB-C2=45W +18W(63W) USB-C1+USB-A=45W +18W(63W) USB-C1+USB-C2+USB-A=45W+10W+10W(65W)]
Power input	100-240V, 1.5A 50/60Hz

### Inner Carton

Number of consumer packagings	6
Length	24.7 cm
Width	16.3 cm
Height	11.1 cm
Length	9.7 inch
Width	6.4 inch
Height	4.4 inch
Gross weight	1.415 kg
Nett weight	1.110 kg
Tare weight	0.305 kg
Gross weight	3.120 lb
Nett weight	2.447 lb
Tare weight	0.673 lb
GTIN	2 48 95229 13265 2



data subject to change  
2023, June 18

Version: 1.3.2  
EAN: 4895229132658

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)