

PHILIPS



In-ear wireless
headphones with mic

8-mm drivers/closed-back

Comfort fit

IPX4 splash/sweat resistant

Great passive noise isolation



TAE1205BK

Tangle-free tunes

Keep your music close. These splash- and sweat-resistant wireless headphones give you great sound, a comfortable in-ear fit and up to 7 hours of play time. When you need more, a quick 15-minute charge keeps the music playing for another 1 hour.

Easy comfort. Secure fit.

- 3 interchangeable rubber earbud covers
- Oval acoustic tube fits comfortably in your ear canal
- Secure, flexible, comfortable
- Wing tips for a secure fit. Better passive noise isolation

Splash resistant. 7 hours of play time.

- 8 mm neodymium drivers. Great sound
- 7 hours of play time. USB-C charging
- IPX4 splash- and sweat-resistant
- Charge for 15 minutes, get 1 hour play time

From playlists to calls

- Inline remote. Easily switch from playlist to calls
- Smart pairing. Automatically find Bluetooth devices
- Built-in mic with echo cancellation for clear audio
- Magnetic earbuds. Flat, tangle-resistant cable

Specifications

Sound

Frequency range: 20–20,000 Hz

Speaker diameter: 8 mm

Impedance: 32 Ohm

Maximum power input: 5 mW

Sensitivity: 108.5 dB (1k Hz)

Distortion (THD): <3% THD

Driver type: Dynamic

Connectivity

Microphone: Built-in microphone

Bluetooth version: 5.1

Wireless

Bluetooth profiles: A2DP, AVRCP, HFP

Maximum range: Up to 10 m

Type of wireless transmission: Bluetooth

Outer Carton

Length: 19 cm

Number of consumer packages: 3

Width: 11.2 cm

Gross weight: 0.339 kg

Height: 12.8 cm

GTIN: 1 48 95229 11031 8

Net weight: 0.132 kg

Tare weight: 0.207 kg

Convenience

Volume control

Water resistance: IPX4

Magnetic earbuds

Type of controls: Button

Power

Rechargeable

Number of batteries: 1 pcs

Music play time: 7 hour(s)

Talk time: 5 hr

Charging time: 2 hour(s)

Fast charging time: 15mins for 1 hr

Battery weight (Total): 2.2 g

Battery capacity (Headphones): 100 mAh

Battery life standby time: 60 hr

Battery type (Headphones): Lithium Polymer (built-in)

Packaging dimensions

Height: 17.2 cm

Packaging type: Box

Type of shelf placement: Hanging

Width: 9.5 cm

Depth: 3 cm

Number of products included: 1

EAN: 48 95229 11031 1

Gross weight: 0.081 kg

Net weight: 0.044 kg

Tare weight: 0.037 kg

Product dimensions

Cable length: 64 cm

Height: 1.5 cm

Width: 2.5 cm

Depth: 0 cm

Weight: 0.015 kg

Accessories

Quick Start Guide

Eartips: 3 pairs (S/M/L)

Charging cable: USB-C cable

Design

Colour: Black

Wearing style: In-ear

Ear coupling material: Silicone

Ear fitting: In-ear

In-ear fitting type: Silicone ear-tip

UPC

UPC: 8 40063 20150 7

Voice assistant

Voice assistant compatible

Voice assistant activation: Manual

Voice assistant support

Highlights

IPX4

With an IPX4 rating, these true wireless headphones are resistant to splashing from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

Secure, flexible, comfortable

Flexible wing tips fit under the ridge of your ear, enabling a secure fit and better passive noise isolation. An oval acoustic tube and interchangeable earbud covers enable a comfortable in-ear fit. The flat headphone cable sits comfortably behind your neck whether the earbuds are in or out.

Magnetic earbuds.

These headphones have magnetic earbuds that stick together and a flat headphone cable that resists tangling. When you pull them out of a bag or pocket, you won't have to untie a knot before you can tune in to your playlist.

Inline remote.

Take a call, pause your playlist. All without touching your smartphone. Smart Bluetooth pairing means these headphones remember the last devices they were paired with.

7 hours of play time.

The 8 mm neodymium drivers deliver great sound and you get up to 7 hours play time from a 2 hour charge via USB-C. If you start running low on power, a quick 15 minute charge will keep the music playing for another 1 hour.

