



Slim design, fits anywhere

Enjoy your favorite CD or radio stations in the kitchen, with its ultra slim design, it fits virtually anywhere under the cabinet, yet delivering easy to use features such as 5 one touch preset memory & magnetic remote control.

Superb performance in a compact design

- Play CD, CD-R and CD-RW discs
- · Digital tuning with preset stations for extra convenience
- Built-in kitchen clock with cooking timer
- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- Under cabinet design for space saving
- 5 one touch buttons for easy access to favorite radio tunes
- · Motorized CD loader for convenience access
- Easy to clean
- · Remote control with built-in magnet



Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW
- Disc playback modes: fast forward/backward, next/ previous track search, repeat/shuffle/program

Tuner/Reception/Transmission

- Tuner bands: AM, FM
- Station presets: 25
- · Tuner enhancement: auto digital tuning

Sound

- · Sound enhancement: Dynamic Bass Boost
- · Sound system: stereo
- Volume control: up/down
- Output power: 2 x 2 W RMS

Convenience

- Alarms: buzzer alarm
- Backlight color: green
- Display Digits: 5
- · Loader type: front
- Display type: LCD display
- · Height adjustment: 4-step spacer
- · Clock: Digital



Accessories

- Cables/Connection: power cord
- Remote control
- Others: batteries for remote control, Quick start
- guide, User Manual
- Warranty: Warranty Certificate

Dimensions

- Gross weight: 3.43 kg
- Packaging width: 371 mm
- Packaging height: 396 mm
- Packaging depth: 119 mm
 Weight: 2.84 kg
- Main unit depth: 312 mm
- Main unit height: 68 mm
- Main unit width: 330 mm

Power

- Battery voltage: 1.5 V
- Number of batteries: 2
- Power type: AC Input

Loudspeakers

· Loudspeaker enhancement: bass reflex speaker system

.]6111/37

Highlights

Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD,CD-R and CD-RW. A singe CD can store up to 10 hours of music. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Under cabinet design

Under cabinet design for space saving

5 one-touch radio presets

Access your favorite stations with simple one touch operation

Motorized CD loader

A motorized sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.

Easy to clean Easy to clean

Magnetic remote control

Allows you to stick the remote contorl on any metal surface in the kitchen, such as fridge.



Issue date 2011-07-21

© 2011 Koninklijke Philips Electronics N.V. All Rights reserved.

Electronics N.V. or their respective owners.

Version: 3.7.13

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips

12 NC: 9073 101 02731 UPC: 6 09585 11437 1

www.philips.com