

Philips
Docking Entertainment
System

Bluetooth
USB and SD card slots

BTM630



Enjoy wireless music via Bluetooth® technology

Featuring Bluetooth® technology, the BTM630 Micro Hi-Fi System lets you enjoy music from your mobile phone and PC wirelessly. Complete audio system functions feature built-in mic for hands-free calls and switching between calls and music.

Enjoy freedom with Bluetooth® wireless technology

- Playback mobile phone and PC music via Bluetooth technology
- Built-in microphone and speakers for hands-free mobile calls
- Auto switch between telephone calls and music playback

Organise your home digital music collection

- Play and charge your iPod simultaneously
- USB Direct and SD/MMC card slots for MP3/WMA music playback
- One-touch MP3 digital recording in 2 X speed — no pc needed

Rich and clear sound

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings
- 30 W RMS total output power

Design that blends into your interior

- Elegant design with super-slim CD slot
- All-in-one remote control for the system and for your iPod

PHILIPS

Specifications

Connectivity

- Bluetooth
- Bluetooth profiles: A2DP, AVRCP, Hands-free, Headset
- Bluetooth range: Line of sight, 10 m or 30 ft
- USB: USB host
- SD/MMC card slot
- Aux in
- Headphones: 3.5 mm

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with colour display, iPod 5th Generation, iPod shuffle

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and reverse
- Loader Type: Motorised, Slot
- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Reverse, Next/Previous Track Search, Repeat Play, Shuffle Play
- Programmable Tracks: 20
- USB Direct Modes: Delete, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle

Audio Recording

- Recording formats: MP3
- Recording Media: SD/MMC card, USB device

Sound

- Output power (RMS): 2 x 15 W

- Sound System: Stereo
- Loudspeaker types: Bass Reflex Speaker System
- Sound Enhancement: Dynamic Bass Boost
- Volume Control: Volume Control up/down

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Tuner Enhancements: Auto Store
- Auto digital tuning
- Antenna: FM Antenna

Convenience

- Display Type: LCD
- Backlight
- Remote Control: Multi-functional
- Alarms: Radio Alarm, Repeat alarm (snooze), Sleep timer, 24-hour alarm reset
- Clock/Version: Digital

Power

- Mains power
- Power supply: 100-240 VAC, 50/60 Hz

Accessories

- Included accessories: Remote Control, AC Power Cord, User Manual, Warranty certificate

Dimensions

- Product dimensions (W x H x D): 390 x 140.5 x 200.5 mm
- Packaging dimensions (W x H x D): 496 x 238 x 180 mm
- Weight incl. Packaging: 3.5 kg

Highlights

One-touch 2 x recording speed

Simply plug in your USB mass storage device to the USB port on the Philips audio system and start recording your favourite music from CDs to your USB device or MP3 player in 2 X speed — with one-touch operation and no computer needed.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2017-04-05

Version: 2.0.3

12 NC: 8670 000 36881
EAN: 87 12581 39412 7

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com