

Philips
Portable Speaker System



SBA290



Powerful stereo sound stage

Powerful XSL Acoustics

The slim mono-body of the SBA290 portable speaker system slips easily into your pocket or bag. Share the powerful and realistic stereo sound stage with friends wherever you are, and experience amazing rich bass quality even at low volume.

Powerful Sound

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost electronically enhances the low tones
- Incredible Surround™ enhances the sound stage

Take your music with you

- Universal use with all portable entertainment equipment
- Ultra slim mono body fit easily into pockets and bags
- Carrying pouch protects your speakers when not in use

Always ready to go

- Cable neatly stored when not in use

PHILIPS
sense and simplicity

Specifications

Sound

- Frequency response: 100–20,000 Hz
- Impedance: 3 ohm
- RMS Power rating: 2x3W (6W)
- Sensitivity: 80 dB
- Sound Enhancement: Dynamic Bass Boost, Incredible Surround
- Speaker diameter: 40 mm
- Type: Neodymium

Connectivity

- Cable length: 0.3 m
- Connector: 3.5 mm stereo
- Finishing of connector: Nickel-plated

Convenience

- Bass level control
- Operating time: 6 hours
- Power on indication
- Volume control

Accessories

- AC/DC adapter
- Pouch



Power

- Adapter type: 9 V 500 mA
- Battery type: AAA, LR03
- Battery voltage: 1.5 V
- Number of batteries: 6

Packaging dimensions

- Packaging dimensions (W x H x D): 21.8 x 8.5 x 19 cm
- Gross weight: 0.7305 kg
- Net weight: 0.5574 kg
- Tare weight: 0.1731 kg

Outer Box

- Gross weight: 5.294 kg
- Outer carton (L x W x H): 55 x 24.2 x 23.2 cm
- Net weight: 3.3444 kg
- Tare weight: 1.9496 kg

Inner Box

- Gross weight: 1.5993 kg
- Inner carton (L x W x H): 22.8 x 17.8 x 20.8 cm
- Net weight: 1.1148 kg
- Tare weight: 0.4845 kg

Highlights

XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid-range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet delivers sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimises bass performance from the smallest sound enclosure.

DBB Dynamic Bass Boost



Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

Incredible Surround™

Incredible Surround™ widens the sound stage, giving you the impression of having extra speakers all around you.

For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5 mm plug.

Ultra-compact and lightweight

Super slim and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere. Ultimate portability.

Carrying pouch for speakers

Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

Speaker cable management

With its unique design, cable storage is no longer an issue. Simply pack and go.



Issue date 2009-05-31

Version: 4.0.7

12 NC: 9082 100 04298
EAN: 87 10895 87944 6

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com