



Philips  
Micro music system

with Lightning connector  
for iPod/iPhone  
CD, MP3-CD, USB, FM  
70W max



DCM2170

# Sound that fits your home

Obsessed with sound

Compatible with the iPhone 5's Lightning connector, this Philips micro sound system delivers great sound as well as a great, stylish design. Sit back and relax, enjoy your music your way, with one simple control.

## Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings
- 70W RMS maximum output power

## Enjoy your music from multiple sources

- Fast charging and play music via Lightning connector
- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- Audio-in for portable music playback
- Digital tuning with preset stations for extra convenience

# PHILIPS

Micro music system  
with Lightning connector for iPod/iPhone, CD, MP3-CD, USB, FM, 70W max

DCM2170/12

# Highlights

## Play and charge via Lightning



Enjoy your favorite music while charging your iPod/iPhone via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to work about the battery running out.

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off

of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

## USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.



# Specifications

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Others: ID3-tag support
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop
- Docking playback modes: fast forward and backward, next and previous track, play and pause

## Sound

- Sound enhancement: digital sound control
- Volume control: up/down
- Maximum output power (RMS): 70W

## Loudspeakers

- Speaker types: bass reflex speaker system
- Speaker drivers: 4" woofer with soft dome tweeter

## Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Tuner enhancement: auto digital tuning

## Connectivity

- Audio in (3.5mm)
- USB: USB host

## Convenience

- Alarms: CD alarm, radio alarm, iPod alarm, USB alarm
- Loader type: tray
- Charging device: iPhone, iPod

## Accessories

- Remote control
- User Manual: multi-languages

## Dimensions

- Gross weight: 5.7 kg
- Main speaker dimensions (W x D): 140 x 185 mm
- Main speaker height: 260 mm
- Main unit width: 180 mm
- Main unit height: 177 mm
- Main unit depth: 239 mm
- Packaging width: 224 mm
- Packaging height: 314 mm
- Packaging depth: 518 mm

## Power

- Power supply: 110-240V, 50/60Hz

## iPod compatibility

- Compatible with: iPod nano 7th generation, iPod touch 5th generation

## iPhone compatibility

- Compatible with: iPhone 5



Issue date 2014-06-12

Version: 1.0.8

12 NC: 8670 001 01979  
EAN: 87 12581 68401 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)