

Philips
Portable MP3-CD Player
with 100-second Magic
ESP™ and Dynamic Bass
Boost

MP3-CD playback

EXP2368



Enjoy skip-free MP3 music

Get into your groove with the EXP2368 MP3-CD players and enjoy 10 hours of skip-free music on one MP3-CD. A classic favourite, it comes with LCD display and is a great choice for easy and hassle-free music enjoyment on the go

Play your CDs and MP3-CDs

- Enjoy over 10 hours of music on one MP3-CD
- Play CD, CD-R and CD-RW discs

Jogproof

- 100-second Magic ESP™

Enhanced bass performance

- Dynamic Bass Boost for deep and dramatic sound

PHILIPS

Specifications

Sound

- D/A converter: 1-bit
- Frequency response: 20 - 18 000 Hz
- Signal to noise ratio: > 85dB
- Sound Enhancement: Dynamic Bass Boost
- Output Power: 2 x 4mW RMS
- Volume Control: digital

Audio Playback

- Playback Media: MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Hold, Next/Previous Album Search, Next/Previous Track Search, Repeat Play, Shuffle Play
- Magic ESP (MP3-CD): 100 seconds
- MP3 bit rates: 32 - 320 kbps

Connectivity

- Headphone: 3.5 mm



Convenience

- Display Type: LCD
- Indications: album number, battery status, Cd functions, DBB, ESP, time, track

Accessories

- Headphones
- Included accessories: User Manual

Dimensions

- Packaging dimensions (W x H x D): 174 x 208 x 42 mm
- Packaging type: Clamshell
- Product dimensions (WxDxH): 145x145x28mm
- Product weight: 0.235 kg

Power

- Battery type: AA, LR6, UM3

Highlights

10 hours MP3 music on one CD



Enjoy over 10 hours of music on one MP3-CD

Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

100-second Magic ESP™



Magic Electronic Skip Protection™ is a convenient feature that ensures skip-free music even when your MP3-CD player is subjected to knocks and jolts while you are jogging or on the move. Devices with Magic Electronic Skip Protection™ have an intelligent electronic buffer that can store different digital music formats such as MP3, WMA. The buffer adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2023-11-13

Version: 2.0.1

12 NC: 8670 001 84292
EAN: 69 51613 95439 3

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com