

Philips  
Portable CD Player



AX2300

## Jogproof

With its easy-to-use approach to portable music, you will love the AX2300 CD player. You get versatile CD playback, uninterrupted music and everything you need for music on the go in an attractive metallic silver, tear drop shape.

### Enhanced bass performance

- Digital Dynamic Bass Boost for optimised bass at any volume

### Jogproof

- ESP for skip free music on the move

### Enjoy all kinds of discs

- Plays CD, CD-R and CD-RW discs

**PHILIPS**

sense and simplicity

# Specifications

## Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 4 mW RMS
- Signal to noise ratio: > 82 dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: Analogue Volume Control

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30 track programmable, Fast Forward/Reverse, Hold, Introscan, Repeat Play, Resume Playback from stop, Shuffle Play
- Electronic Skip Protection (CD): 45

## Connectivity

- DC in: 4.0 mm, 4.5 V, centre +
- Headphones: 3.5 mm
- Line-out: 3.5 mm

## Convenience

- Display Type: LCD
- Indications: battery status, CD functions, DBB,

ESP, time, track

## Accessories

- Headphones: SBC HE035
- Included Accessories: User manual

## Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body
- Master carton dimensions: 233 x 345 x 256 mm
- Master carton quantity: 3
- Master carton weight: 2.5 kg
- Packaging dimensions (W x H x D): 210 x 300 x 60 mm
- Packaging type: Clamshell
- Product dimension (W x D x H) inch: 125x135x30mm
- Product weight: 0.24 kg

## Power

- Battery Playing Time CD: 72
- Battery type: AA, LR6, UM3
- Kind of Battery: Rechargeable
- Rechargeable

# Highlights

## Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimised bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

## Electronic Skip Protection

Electronic Skip Protection ensures skip free music even when your player is subjected to knocks and jolts while you're jogging or on the move. As your CD plays, music is constantly fed into the player's memory buffer, which temporarily stores your music. When the device is subjected to knocks or jolts - accidentally or during sports - you will still experience uninterrupted sound from the music stored in the buffer while the laser promptly refocuses to the point at which the shock occurred, and recommences playing to refill the buffer.

## Plays CDs, CD-R and CD-RW

Plays CD, CD-R and CD-RW discs



Issue date 2011-07-21

Version: 2.0.3

12 NC: 9073 101 01057  
EAN: 87 10895 80667 1

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)