



Philips  
Universal remote control

4in1 Germany SAT

SRU5040



## Full function replacement

Operates more than 1000 brands

A stylish chrome universal remote control that gives you complete control over most brands of TV, DVD player/recorder, VCR satellite receiver or cable set-top box. It has dedicated satellite keys and learns codes from your old remote.

### Ideal replacement for your old remote

- 4-in-1 remote for your TV, DVD player/recorder, STB and VCR
- Convenient IR learning from another remote
- Ready for use with Philips equipment

### Great convenience

- Dedicated Premiere/Kabel D. keys for Digital STB box control
- Eye-catching chrome finish
- Drop it, splash it and just keep on using it!
- Battery low indication shows when to refresh batteries

### Quick and easy set-up

- Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

# PHILIPS

# Specifications

## Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE
- TV functions: Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- SAT/CBL functions: Digit keys, Menu control, Guide, info, Favourites, Text functions, Unique SAT provider functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: D
- Number of keys: 40
- Preprogrammed for Philips
- Regulatory approvals: CE Mark
- Splash proof

## Accessories

- Battery: Yes, 1.5V Battery R03/AAA

## Infrared Capabilities

- Operating distance: 33 ft (10 m)

- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1100
- Carrier frequency range: 24 - 55 kHz
- Transmission angle: 90 degree
- Learning IR codes
- Learning frequency range: 20 kHz to 70 kHz and 455 kHz

## Power

- Battery lifetime: 12 Months
- Number of batteries: 2
- Battery type: AAA

## Outer Carton

- Quantity: 6
- EAN/UPC/GTIN: 87 10895 93597 5
- Height: 172 mm
- Length: 312 mm
- Width: 151 mm

## Packaging Data

- 12NC: 908210006481
- EAN/UPC/GTIN: 87 10895 93596 8
- Height: 33 mm
- Length: 304 mm
- Width: 157 mm

# Highlights

## 4-in-1 remote control

Replace a table full of remote controls with one robust unit that operates your TV, DVD player/recorder, satellite receiver, digital terrestrial receiver or cable set-top box (STB) and VCR, regardless of the brand or model.

## Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

## Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

## Dedicated Premiere/KD keys

Specially labelled function keys on the remote control make operating your Premiere/Kabel Deutschland digital set-top box easier than ever before.

## Chrome finish

Stylish chrome finish that looks good and complements the latest equipment design.

## Splash and shock resistant

The tough housing can withstand splashes and spilled drinks, and is able to withstand a drop of at least one meter onto a hard floor.

## Battery-low indication

To know in time when the batteries need to be recharged or replaced.

## Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2014-02-05

Version: 1.0.5

12 NC: 9082 100 06481  
EAN: 87 10895 93596 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)