

Philips  
CD Soundmachine

MP3

AZ6188



## A Language Lab Right at Home

For the aspiring linguist and music lover, the compact AZ6188 features superb sound performance and unique features for music enjoyment and language learning right at home. Multifunctional yet easy-to-use – it's all you'll ever need!

### **Easy language learning experience**

- Speech Tempo for experiencing various speech environments
- Language Learning functions for convenient learning

### **Rich and clear sound**

- Bass Reflex Speaker System delivers a powerful, deeper bass
- 10.2 cm (4") full range speakers for powerful sound

### **Enjoy favorite music from three different sources**

- MP3-CD, CD-R/RW compatible
- FM/MW tuner for radio enjoyment
- Autostop cassette deck

**PHILIPS**

# Specifications

## Sound

- Output power (RMS): 2X1W
- Sound System: Stereo
- Volume Control: rotary

## Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

## Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

## Audio Recording

- Recording Media: Flash, Tape
- Tape Recording Enhancement: CD Synchro Start Recording

## Audio Capturing

- Built-in microphone: mono

## Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning: No
- Tuner Bands: FM, MW

## Connectivity

- Headphone: 3.5 mm

## Convenience

- Display Digits: 9
- Display Type: LCD

## Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate

## Dimensions

- Packaging dimensions (W x H x D): 470 x 211 x 260 mm
- Product dimensions (W x H x D): 400 x 173 x 240 mm
- Weight: 2.8 kg
- Weight incl. Packaging: 3.5 kg

## Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

# Highlights

## Speech Tempo

Speech Tempo technology lets you alter the playback speed of an audio signal without affecting its original pitch. In particular, you can experience different conversation environments - from leisurely chat to urgent discussion - by controlling the speed of language learning content. By pressing the Speech Tempo key you can select a faster or slower speed of speech from the original learning material without any distortion in comprehension. Choose from five preset speeds: Slow II, Slow I, Normal, Fast I, Fast II to simulate how native speakers would converse in different environments.

## Language Learning functions

Language Learning functions are special functions - Repeat, Follow and Compare - that let you use your audio set as a laboratory for language learning. The functions work with tape, CDs or MP3-CDs. Selecting the 'Repeat' function lets you listen repeatedly to selected content; 'Follow' lets you listen and then recite, and 'Compare' lets you compare your recitation to the original content.

## Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## 10.2 cm/4" full range speakers

10.2 cm (4") full range speakers for powerful sound

## MP3-CD, CD-R/RW compatible

MP3-CD, CD-R/RW compatible

## FM/MW tuner

FM/MW (AM) stereo tuner

## Autostop cassette deck

Autostop cassette deck

