

Philips
Micro music system

DAB+
CD, MP3-CD, USB, FM
150 W

BTB3370



Relax to great music

Lose yourself in music, streamed over Bluetooth, on a CD or even via USB direct. Then tune in to your favourite radio shows with DAB+ and FM compatibility. This Philips micro system brings you everything, with 150W of maximum output power.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimised music style settings
- 150W RMS maximum output power

Enjoy your music from multiple sources

- Stream music over Bluetooth with multi-device pairing
- DAB+ and FM compatible for a complete radio experience
- Play MP3-CD, CD and CD-R/RW
- USB Direct for easy MP3 music playback
- Audio-in for portable music playback

Easy to use

- Motorised CD loader for convenient access
- Digital tuning with preset stations for extra convenience
- Swap music instantly between 2 Bluetooth devices

PHILIPS

Highlights

Multi-device pairing

Wireless Bluetooth® sound transmission is increasingly common in the world of sound systems, but most Bluetooth® compatible systems allow just one device to connect at a time. Multi-device pairing lets you pair up to two devices and switch between them instantly.

DAB+ and FM compatible

DAB+ and FM compatible for a complete radio experience

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to

create a completely new dimension of deep bass.

Audio-in



The Audio-in connectivity allows direct playback of Audio-in content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of

accessing more digital music via the built-in USB Direct.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Balance, Clear, Powerful, Warm and Bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Specifications

Sound

- Sound enhancement: digital sound control
- Maximum output power (RMS): 150 W

Loudspeakers

- Speaker drivers: 3" woofer
- Speaker types: bass reflex speaker system

Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Bluetooth: Play/Pause, Previous/Next

Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan
- DAB/DAB+: Info display, Smart scan

Connectivity

- USB: USB host
- Audio in (3.5 mm)

- Bluetooth
- Bluetooth profiles: A2DP, AVRCP

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display type: LED display
- Loader type: tray

Accessories

- Included accessories: FM antenna, User Manual
- Remote control: 21-key remote with battery

Dimensions

- Main unit width: 249 mm
- Main unit height: 128 mm
- Main unit depth: 275 mm
- Main speaker dimensions (W x D): 140 x 215 mm
- Main speaker height: 306 mm
- Packaging width: 490 mm
- Packaging height: 313 mm
- Packaging depth: 356 mm
- Gross weight: 8.6 kg
- Net weight: 7.4 kg

Power

- Power supply: 220-240 V, 50 Hz



Issue date 2016-06-30

Version: 3.0.3

12 NC: 8670 001 27155
EAN: 48 95185 61168 6

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com