



Philips  
CD Soundmachine with  
Dynamic Bass Boost

VCD  
MP3  
cassette

AZ5140

## VCD / MP3-CD Soundmachine

With AZ5140, you can playback your favorite VCD movies, MP3-CD, cassette tape or enjoy your favorite radio stations through the two powerful stereo speakers.

### Feature-packed VCD and CD player

- VCD2.0 playback
- MP3-CD playback means MP3 plays like a normal audio CD.
- FM/MW stereo tuner
- Autostop stereo cassette deck

### Rich and clear sound experience

- Dynamic Bass Boost for deep and dramatic sound
- Bass Reflex speakers deliver a powerful, deeper bass
- 3" full range speakers

### Easy to use

- On Screen Display for easy navigation
- 9 frames digest preview for easy navigation
- Super Error Correction for distortion-free VCD playback
- PAL/NTSC compatible
- Handy remote control

# PHILIPS

# Specifications

## Video Playback

- Playback Media: Video CD/SVCD
- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, Introsan, OSD, Pause, PBC, Slow Motion, Zoom

## Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Number of decks: 1
- Cassette Deck Technology: Mechanical

## Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Antenna: FM Antenna

## Sound

- Output power (RMS): 2X1W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- Speaker diameter: 3"
- Volume Control: rotary

## Loudspeakers

- Built-in speakers: 2
- Finishing: Metal

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

## Connectivity

- Video Output - Analog: Video (3.5mm jack) 1x
- Audio output: Stereo Audio (3.5 mm jack) 1x

## Convenience

- Display Type: LCD
- Display Digits: 3

## Power

- Battery type: LR14
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

## Accessories

- Remote control: 33 keys
- Included Accessories: AC Power Cord, Audio/Video cable, User Manual, Warranty certificate

## Dimensions

- Packaging dimensions (W x H x D): 410 x 200 x 308 mm
- Product dimensions (W x H x D): 361 x 159 x 257 mm
- Weight: 2.85 kg
- Weight incl. Packaging: 3.65 kg

# Highlights

## VCD2.0 playback

VCD2.0 playback

## MP3-CD playback


MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.



Issue date 2021-08-16

Version: 2.1.7

12 NC: 9073 101 02468  
EAN: 87 10895 94643 8

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)