

Philips
DVD Micro Theatre

DivX playback

MCDB710

DAB radio

## Enjoy crystal clear sound from DAB radio

## with DVD playback

Enjoy superb clarity and built-in DAB tuner with the MCDB710 DVD Micro Theatre. The one block complete centre unit adds a touch of style to any interior with the wood-finished speakers that deliver high-quality sound.

## Enjoy digital quality DAB radio

- DAB and FM compatible for a full radio experience
- · Tune into digital-quality radio stations

## **Enrich your movie experience**

- Dolby Digital for ultimate movie experience
- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD

## **Enrich your sound experience**

- $2 \times 50$  W RMS total output power
- View photos and listen to music directly from USB devices
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- · Loudness for bass and treble enhancement



# Highlights

## **USB** Direct plays photos/music

Simply plug your USB device into the system and share your stored digital music and photos with your family and friends.

### **Digital Sound Control**

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## **Dynamic Bass Boost**

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

#### **Dolby Digital**

Because Dolby Digital standards, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

#### Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. With the Loudness feature activated, the bass and treble will be amplified so you can savour a more balanced sound perception overall.

## **DAB** and **FM** compatible

DAB (Digital Audio Broadcasting) digital radio is a new way of broadcasting radio, in addition to FM analogue transmission, via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.

















## **Specifications**

#### Sound

- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost
- · Sound System: Dolby Digital
- Output Power: 2 x 50 W RMS/2 x 100 W music power

#### Loudspeakers

 Main Speaker: 2-way, 4" woofer, Bass Reflex Speaker System, Speaker grilles detachable, Piezo tweeter

## Video Playback

- Playback Media: DVD-Video, Video CD/SVCD, Picture CD, DivX, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: Parental control, Angle, Zoom, A-B Repeat, Disc Menu, Fast Reverse, Fast Forward, OSD, PBC, Slow Reverse, Slow Forward
- DVD Region.: 2

## **Still Picture Playback**

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/ +RW

## **Audio Playback**

- Playback Media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search
- · Loader Type: Motorised, Tray
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- ID3-tag support

## Tuner/Reception/Transmission

- · Auto digital tuning
- Tuner Bands: FM Stereo
- RDS: Programme Type, Radio Text, RDS Clock Set. Station Name

- Tuner Enhancements: Auto Store
- DAB: Band III, Info display, Menu, Smart Scan
- Station presets: 20

### **Connectivity**

- Video Output Analogue: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Other connections: Digital audio coaxial out, Fixed FM and DAB T-shape antenna
- Headphones: 3.5 mm
- USB: USB host
- Audio Connections: Analogue Audio In (L/R), Analogue Audio Out (L/R)

#### Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- · Clock: On main display
- Display Type: Dot Matrix LCD
- OSD Languages: English, Dutch, French, German, Italian, Portuguese, Spanish, Swedish, Turkish
- · Eco Power Standby: 1 watt
- Indications: DIM mode

#### **Accessories**

- Included accessories: Composite video cable (Y), DAB antenna, FM antenna, World Wide Warranty leaflet
- User Manual: English, Danish/Norwegian
- Quick start guide: English, Danish, Norwegian
- Remote control: 47-key with battery

#### **Dimensions**

- Main speaker dimensions (W  $\times$  H  $\times$  D): 170  $\times$  270  $\times$  220 mm
- Packaging dimensions (W  $\times$  H  $\times$  D): 558  $\times$  350  $\times$  314 mm
- Set dimensions (W x H x D): 248 x 110 x 307 mm
- Weight incl. Packaging: 10.5 kg

## Power

• Power supply: 220-240 V, 50 Hz



Issue date 2010-10-28

Version: 1.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 39647 EAN: 87 12581 42199 1

www.philips.com