



### True Wireless Headphones

- Hybrid Active Noise Cancelling
- 2 x 2 mics for clear voice calls
- Pocket-sized charging case
- IPX4 splash/sweat resistant

TAT4507SL/00

## Never miss a beat.

These True Wireless headphones with 10 mm drivers and Hybrid Active Noise Cancelling let you hear the sounds that matter. With a hockey-stick design, IPX4 splash and sweat resistance and a pocket-sized charging case for 24 hours of play time.

### Benefits

#### Great sound. Sleek looks

- Hybrid Active Noise Cancelling
- 2 x 2 microphones for crystal-clear voice calls
- 10 mm neodymium drivers for great sound
- Hockey stick design

#### Comfort and convenience

- Secure, comfortable in-ear fit
- IPX4 splash and sweat resistant
- Includes 3 sizes of ear-tip cover

- Touch controls

#### Pocket-sized charging case

- Portable charging case
- 6 + 20 hours play time for a full day's listening
- Charging case dimensions: 62 x 38 x 29 mm
- Quick charge for 15 minutes and get an extra hour

# PHILIPS

## Features

### Active Noise Cancelling



These headphones feature Hybrid Active Noise Cancelling that filters out the noise you don't want to hear. Awareness Mode means you can let the world back in when you need to. The perfect way to pay tribute to your favourite sounds!

### 2 x 2 mics for clear calls



These headphones feature a dual-mic, noise-cancelling algorithm to give you fantastic call clarity. Two beam-forming microphones in each bud reduce the ambient noise so that you can hear each other distinctly. Communicate clearly every time!

### Secure, comfortable fit



These comfortable earbuds fit securely into your ear canals, creating a perfect seal that diminishes external noise. Hear every beat and word! Enjoy real comfort with three sizes of soft, interchangeable silicone ear-tip covers.

## Specifications

Please note that this is a pre-sales leaflet. The contents of this leaflet reflect the best of our knowledge per date and country mentioned above. The contents of this leaflet are subject to change without notice. Philips does not accept any liability as to the contents of this leaflet.

### Sound

Impedance	16 Ohm
Speaker diameter	10 mm
Sensitivity	105 dB(1k Hz)
Frequency range	20–20,000 Hz
Maximum power input	10 mW
Driver type	Dynamic

### ANC features

ANC (Active Noise Canceling)	Yes
ANC technology	Hybrid
Awareness mode	Yes
Microphone for ANC	4 mic

### Connectivity

Bluetooth version	5.2
Supported codec	AAC SBC
Maximum range	Up to 10 m
Bluetooth profiles	A2DP AVRCP HFP

### IPX4 splash/sweat resistant

An IPX4 rating and powerful 10 mm drivers let you enjoy great sound in any weather! The headphones are splash resistant and won't mind a little rain or sweat, so you don't need to worry about getting caught in a shower.

### Pocket-sized case

This USB-C charging case gives you real power in a tiny package. You get a full day of listening from a case that slips into the smallest pocket. This makes these headphones perfect for those who are on the move throughout the day.

### 26 hours play time

No matter how long your day is, these headphones have got you covered. You get 6 or 5 hours of play time from a pair of fully charged earbuds with ANC off and ANC on respectively. A fully charged case gives you another 20 or 16 hours respectively.

Type of wireless transmission	Bluetooth
Wireless	Yes

### Convenience

Philips Headphones app support	Yes
Firmware updates possible	Yes
Water resistance	IPX4
Mono mode for TWS	Yes
Type of controls	Touch

### Design

Colour	Silver
Ear fitting	In-ear
In-ear fitting type	Silicone ear-tip
Ear coupling material	Silicone

### Power

Music play time (ANC off)	6 + 20 hr
---------------------------	-----------

Music play time (ANC on)	5 + 16 hr
Battery type (Earbud)	Lithium Polymer (Built-in)
Battery capacity (Earbud)	40 mAh
Battery type (Charging case)	Lithium Polymer (Built-in)
Battery capacity (Case)	450 mAh
Charging time	2 hr
Fast charging time	15 mins for 1 hr
Number of batteries	3 pcs
Battery weight (Total)	10.26 g
Rechargeable	Yes

#### Voice assistant

Voice assistant support	Yes
Voice assistant compatible	Apple Siri Google Assistant
Voice assistant activation	Manual

#### Accessories

Eartips	3 pairs (S/M/L)
Charging case	Yes
Charging cable	USB-C cable, 500 mm
Quick Start Guide	Yes

#### Dimensions

Earbud dimension (W x D x H)	3.3 x 2.1 x 2.3 cm
Charging case dimension (W x D x H)	6.2 x 3.8 x 2.9 cm
Total weight	0.043 kg

#### Packaging dimensions

Packaging type	Box
----------------	-----

Number of products included	1
Type of shelf placement	Hanging
EAN	48 95229 12900 9
Depth	3.5 cm
Gross weight	0.125 kg
Height	17.2 cm
Net weight	0.067 kg
Tare weight	0.058 kg
Width	9.5 cm

#### Inner Carton

Number of consumer packages	3
GTIN	2 48 95229 12900 3
Gross weight	0.516 kg
Height	11 cm
Length	16 cm
Net weight	0.201 kg
Tare weight	0.315 kg
Width	11.5 cm

#### Outer Carton

Number of consumer packages	24
GTIN	1 48 95229 12900 6
Gross weight	4.575 kg
Height	25 cm
Length	33.8 cm
Net weight	1.608 kg
Tare weight	2.967 kg
Width	24.5 cm

#### UPC

UPC	8 40063 20265 8
-----	-----------------

\* Battery life of play time is approximate and may vary depending on application condition.



data subject to change  
2023, June 19

Version: 4.1.2  
EAN: 4895229129009

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)