

Philips docking entertainment system

AZ1330D

Share your iPod music at home or on the go

Free your iPod music and enjoy it out loud on the Philips AZ1330D with powerful 2x4W sound. Share all your tunes and liven up any party, or just slide in a CD on the motorized loading tray to enjoy your favorite music at home.

Enjoy your favorite music

- · Play and charge your iPod simultaneously
- Play MP3/WMA-CD, CD and CD-RW
- · Digital tuning for station presets

Superb performance in a compact design

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound
- 8W RMS total output power

Easy to use

- Motorized CD loader for convenience access
- · Make album selection from MP3 and WMA music
- Single remote control for the system and iPod



Specifications

iPod compatibility

· Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th Generation

Audio Playback

- Cradle playback mode: Charging iPod, Play and Pause, Next and Previous track, Fast forward and
- · Loader Type: Motorised, Tray
- Playback Media: WMA-CD, MP3-CD, CD, CD-R,
- · Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle
- Programmable Tracks: 20

Sound

- Output power (RMS): 2x4 W
- · Sound System: Stereo
- Loudspeaker types: Bass Reflex Speaker System
- Sound Enhancement: Dynamic Bass Boost
- · Speaker diameter: 3'
- Volume Control: rotary

Tuner/Reception/Transmission

- · Tuner Bands: FM, MW
- · Auto digital tuning
- Station presets: 25

Made for iPod

· Antenna: FM Antenna











Connectivity

- Aux in
- · Headphone: 3.5 mm

Convenience

- Display Type: LCD
- Backlight
- · Remote Control: Multi-functional

Power

- Mains power
- Battery type: LR20
- Battery voltage: 1.5 V
- Number of batteries: 6

Accessories

· Included accessories: Remote Control, Audio Cable, AC Power Cord, User Manual, Warranty certificate

Dimensions

- Packaging dimensions (W x H x D): 410 x 187 x 307 mm
- Product dimensions (W x H x D): 358.4 x 140.6 x 260 mm
- Weight: 2.22 kg
- Weight incl. Packaging: 3.15 kg



Issue date 2014-02-06

Version: 3.0.13

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 30974 EAN: 87 12581 34184 8

www.philips.com

Highlights

Play and charge your iPod

Enjoy your favorite MP3 music while charging your iPod! The dock lets you connect your iPod directly to the Docking entertainment system so you can listen to your favorite music in superb sound. It also charges your iPod while it plays so you can enjoy your music and not have to worry about your iPod battery running out. Use the remote control to navigate, select and playback the music stored on your iPod. The Docking entertainment system automatically charges your iPod while it is docked.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Motorized CD loader

A motorized sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.