

Philips
Micro Hi-Fi System

Compact design
MP3-CD and tape playback

MCM149



Obsessed with sound

Relax with great music

Appreciate fantastic sound from the truly compact and stylish Philips micro hi-fi system. Enjoy your favorite MP3-CD music richly enhanced by powerful Dynamic Bass Boost.

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings
- 4W RMS total output power

Easy to use

- Autostop cassette deck
- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience

Fits any space, any lifestyle

- Compact design
- Handy remote control

PHILIPS

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be

switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output power: 2 x 2 W RMS / 200 W PMPO
- Sound enhancement: Dynamic Bass Boost, digital sound control 4 modes
- Volume control: up/down

Loudspeakers

- Speaker drivers: 3" woofer

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Cassette deck technology: mechanical

Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording, automatic recording level

Tuner/Reception/Transmission

- Tuner bands: FM stereo, MW
- Station presets: 20
- Antenna: FM fixed pigtail antenna, MW antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: 2xRCA (Audio), Headphone

(3.5mm)

Convenience

- Alarms: CD alarm, radio alarm
- Clock: on main display, sleep timer
- Loader type: top
- Display type: LCD display
- Backlight color: blue

Accessories

- Remote control
- User Manual: English
- Others: FM/MW antenna, Quick start guide
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 4.75 kg
- Main speaker dimensions (W x D): 134 x 152 mm
- Main speaker height: 230 mm
- Main unit depth: 216 mm
- Packaging width: 370 mm
- Main unit height: 233 mm
- Packaging height: 270 mm
- Main unit width: 148 mm
- Packaging depth: 326 mm

Power

- Power supply: 100 - 240V AC, 50/60Hz



Issue date 2016-10-05

Version: 2.0.2

12 NC: 8670 000 34206
EAN: 87 12581 36587 5

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com