



How to mount your system onto wall

The wall mounting instructions are only for use by qualified wall mounting personnel.

Ask a qualified person to help you with the wall mounting, which includes drilling holes on the wall and mounting the set onto wall. What else you'll need?

Drilling tools (e.g. an electrical drill).

Find a suitable location for mounting and complete the necessary rear connections.

The person for wall mounting should:

- learn about the piping, wiring and other relevant information inside your wall, to avoid unexpected damage;
- choose suitable drilling tools according to the drilling requirements;
- take other precautions necessary for the wall mounting work.

A Mounting your main unit onto wall **IMPORTANT!**

- Leave adequate space on both sides of the main unit to facilitate disc door opening!

- 1 Find an appropriate location on the wall and use the wall mounting bracket for the main unit as a template to drill four 6mm-diameter holes.
- 2 Secure four screws (supplied) in the holes.
- 3 Hook the main unit onto the bracket.

B Mounting your speakers onto wall

- 1 Detach the stand from any speaker. Place the detached screws aside for step 3.
- 2 Drill two 6mm-diameter holes at the chosen locations on the wall, with 46mm between them.
- 3 Secure the screws (obtained from step 1) in the holes respectively, leaving the screws 5mm proud of the wall.
- 4 Install the bracket on the speaker with screws as shown.
- 5 Hook and mount the speaker in place.

Repeat the steps above to mount the other speaker.

C Install the DIN cable and cabling channel (optional) onto wall

- 1 Fix the bottom half of the DIN cable on the wall with screws as shown.
- 2 Guide the DIN cable between the main set and the subwoofer into the cabling channel.
- 3 Fit the upper half of the cabling channel on the bottom piece as shown.