



Philips  
Universal remote control

4-in-1 TV/DVD/SAT/AMP

SRU7140



## Compact controller for home cinema

Operates more than 1200 brands

If you own a Flat TV and matching home entertainment centre, this elegant slim slider style remote control adds the finishing touch! The stylish remote provides all main functions of your home entertainment equipment in one fun package.

### **A touch of elegance**

- Compact "slider" remote that opens to full size controller
- Direct access to main keys, additional functionality hidden

### **Single control solution for most devices and brands**

- 4-in-1 remote for your TV, STB, DVD and Receiver

### **Great convenience**

- Convenient IR learning from another remote
- Ready for use with Philips equipment

# PHILIPS

# Specifications

## Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/Brightness control, Teletext keys, Fast text keys, Previous programme, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control
- SAT/CBL functions: Digit keys, Menu Control, Guide, info, Favourites, Text functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: GB/FR/DE/IT/ES/NL/DK/SV/N/FIN/P/GR
- Number of keys: 31
- Pre-programmed for Philips
- Regulatory Approvals: CE Mark
- Splash-proof

## Power

- Battery lifetime: 12 months
- Number of batteries: 2
- Battery saving manager: Auto switch on/off

## Infrared Capabilities

- Operating distance: 7 m
- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1200
- Carrier frequency range: 28–70kHz
- Transmission angle: 90 degree
- Learning IR codes
- Learning frequency range: 30–60 kHz

## Accessories

- Battery: Yes, CR2032 Coin cell Battery 3V Lithium

## Outer Box

- Length: 306 mm
- Width: 70 mm
- Height: 160 mm
- EAN/UPC/GTIN: 87 12581 31448 4
- Quantity: 3

## Packaging Data

- 12NC: 867000026263
- EAN/UPC/GTIN: 87 12581 30765 3
- Height: 26 mm
- Length: 302 mm
- Width: 155 mm

# Highlights

## Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

## 4-in-1 home entertainment remote

Replace a table full of remote controls with one unit that'll operate your TV, satellite receiver (or cable set-top box [STB]) DVD player/recorder and receiver (AMP), regardless of the brand or model.

## Slider mechanism

A slider remote is an elegant, fun and convenient way of controlling your home entertainment equipment.

## Slider functionality

A slider remote provides functionality on the outside of the remote as well as on the inside by sliding it open. The top of the slider remote contains the most commonly used functions. Additional functionality becomes available when the remote is opened.



Issue date 2017-04-04

Version: 1.2.6

12 NC: 8670 000 26263  
EAN: 87 12581 30765 3

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)