



Philips  
Micro Hi-Fi System

CD playback  
Compact design

MC146

## The new classic micro system

Tune in to superb sound from a surprisingly compact and sleek design. The MC146 Micro System will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

### Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Dynamic Bass Boost for deep and dramatic sound
- 4W RMS total output power

### Easy to use

- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience
- Digital tuning with preset stations for extra convenience

### Fits any space, any lifestyle

- Compact design
- Easy-to-use remote control included

# PHILIPS

# Specifications

## Sound

- Output Power: 2x2W RMS / 2x4W music power
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 3" woofer

## Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program
- Loader Type: Top

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20

## Connectivity

- Headphone: 3.5 mm
- Other connections: FM fixed pigtail antenna, MW

- Antenna
- Audio Connections: 3.5mm Line in

## Convenience

- Alarms: Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

## Accessories

- Included accessories: FM/MW Antenna, IFU / User Manual, World Wide Warranty leaflet
- Remote control: 24-key remote control

## Dimensions

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 5.1 kg

# Highlights

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2016-10-05

Version: 2.0.9

12 NC: 8670 000 33204  
EAN: 87 12581 35831 0

© 2016 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)