

Philips Micro Hi-Fi System

MCB700

Digital Sound from DAB Stations

Enjoy superb clarity with built-in DAB tuner with this Micro system. With a mirror-finished center-unit that adds a touch of stylishness to any interior and the wood-finished speakers deliver high quality sound.

Enjoy digital quality DAB radio

- · Tune into digital quality radio stations
- DAB and FM compatible for a complete radio experience

Unlimited listening pleasure

• Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- · Loudness for bass and treble enhancement
- 50W RMS total output power

Design that blends into your interior(s)

- · High-end component design with stand
- · Elegant wood-finished speakers
- High quality remote control for comfortable use



Highlights

DAB and **FM** compatible

DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls

you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a

button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

















Specifications

Sound

- Output Power: 2x25 watts RMS / 2x50 watts music power
- Sound Enhancement: Loudness, Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

 Main Speaker: 2 way, 4" woofer, Bass Reflex Speaker System, Speaker grilles detachable

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD-RW, CD-R, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Top

Tuner/Reception/Transmission

- · Auto digital tuning
- Station presets: 20
- Tuner Bands: FM Stereo
- DAB: Info display, Menu, Smart Scan, Band III
- RDS: Program Type, Radio Text, Station Name

Connectivity

- Aux in: 2x(L/R)/ RCA
- · Headphone: 3.5 mm

Convenience

- Alarms: CD Alarm, Sleep timer
- · Clock: On main display
- Display Type: VFD display
- Eco Power Standby: 1 watt

Accessories

- Included accessories: Control cable, FM antenna, DAB antenna
- Remote control: 38-key with Lithium battery
- · Quick start guide: English
- User Manual: English
- Warranty Card: World Wide Warranty leaflet

Dimensions

- Set dimensions (W x H x D): 208 x 156 x 268 mm
- Main speaker dimensions (W \times H \times D): 145 \times 230 \times 215 mm
- Packaging dimensions (W x H x D): 475 x 275 x 330 mm
- Weight incl. Packaging: 11.5 kg



Issue date 2014-02-10

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 2.0.4

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 100 13513 EAN: 87 10895 98035 7

www.philips.com