

Philips
Portable Speaker System

SBA161



Powerful stereo sound stage

for your Nokia phone

Enjoy powerful and wide stereo sound from your Nokia phone with 2.5mm plug. These speakers pack a lot of punch with a highly efficient, interference free digital amplifier and come with an integrated phone cradle.

Powerful Sound

- Class 'D' digital amplifier for quality sound performance
- Integrated FM Antenna

For superb music pleasure

- Bass pipe emphasizes low tones for a clear, realistic sound
- Powerful speaker drivers for ultra realistic sound
- Wide stereo sound stage when speakers placed apart.

Take your music with you

- Lightweight, portable design for music enjoyment anytime

Always ready to go

- Battery or AC power option for music enjoyment anywhere

Share your music anywhere

- Works with your phone and MP3 players
- Made for Nokia XpressMusic

PHILIPS

Specifications

Sound

- Frequency response: 150 - 20000 Hz
- Impedance: 8 Ohm

Connectivity

- Connector: 2.5mm Nokia connector. Adapter for 3.5mm audio sources included.

Convenience

- Operating time: up to 25 hours

Accessories

- AC/DC Adaptor
- Phone holder: Cradle for Nokia 5200 / 5300 XpressMusic, Universal cradle for other Nokia phones and MP3 players included.

Power

- Battery type: AAA, LR03
- Adaptor type: 6V 500mA
- Battery voltage: 1.5 V
- Number of batteries: 4

Packaging dimensions

- Packaging dimensions (W x H x D):

- 21.8 x 22.3 x 11.5 cm
- Gross weight: 0.889 kg
- Nett weight: 0.654 kg
- Tare weight: 0.235 kg
- EAN: 87 12581 36153 2
- Number of products included: 1
- Packaging type: Carton

Inner Carton

- Inner carton (L x W x H): 24.2 x 22.6 x 20.3 cm
- Gross weight: 1.956 kg
- Nett weight: 1.308 kg
- Tare weight: 0.648 kg
- EAN: 87 12581 36167 9
- Number of consumer packagings: 2

Outer Carton

- Outer carton (L x W x H): 69.6 x 25.7 x 22.3 cm
- Gross weight: 5.996 kg
- Nett weight: 3.924 kg
- Tare weight: 2.072 kg
- EAN: 87 12581 36166 2
- Number of consumer packagings: 6

Highlights

For music enjoyment anywhere

The options of battery and AC power allow the most flexibility with your sound system. You can carry them and enjoy music anywhere you go.

Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

Wide stereo soundstage

These portable speakers create a natural stereo sound stage when they are placed apart, this gives the impression that each musical instrument occupies a different physical space. The effect is more realistic and more enjoyable.

Integrated FM Antenna

For your phones FM radio to work properly it usually needs an external antenna. This Philips product includes an FM antenna so you get quality sound from your phones built-in radio.

Works with phones and MP3

Enjoy music from your mobile phone or your MP3 player! Connect your speaker to your mobile phone or MP3 player with the included adapter.

Made for Nokia XpressMusic

This product has been designed for use with Nokia XpressMusic phones. Extensive testing with these phones make sure you will get the best out of your phone in combination with this Philips product.



Issue date 2014-02-06

Version: 4.0.8

12 NC: 8670 000 33609
EAN: 87 12581 36153 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com