

Philips  
DVD micro music system

with Lightning connector  
DVD

DCD1190



# Relax with great music and movie

## Obsessed with sound

Compatible with the iPhone 5's Lightning connector. This Philips DVD micro music system enrich your music and movie experience with great sound and powerful bass by bass reflex speaker system.

### Enrich your sound experience

- 14W RMS total output power
- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control

### Enjoy your favorite movies and music

- Fast charging and play music via Lightning connector
- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- Karaoke for endless singing entertainment at home
- USB Direct for easy MP3 music playback

### Easy to use

- FM digital tuning to preset up to 20 stations
- Motorized CD loader for convenience access

# PHILIPS

# Highlights

## Play and charge via Lightning



Enjoy your favorite music while charging your iPod/iPhone/iPad via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to worry about the battery running out.

## Play DVD, VCD, MP3-CD, CD(RW) & Pict



The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

## Karaoke for endless singing



Karaoke for endless singing entertainment at home

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set balanced, clear, powerful, warm and bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

# Specifications

## Sound

- Sound Enhancement: Digital Sound Control
- Sound System: Dolby Digital
- Output power (RMS): 14

## Loudspeakers

- Speaker drivers: 3.5" woofer
- Speaker types: bass reflex speaker system

## Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 6
- Video Enhancement: Progressive Scan

## Audio Playback

- Playback Media: MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: Repeat/one/all/program, Fast Forward/Backward, Next/Previous Track Search
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Stop

## Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: Picture CD, CD-R/RW, DVD+R/+RW

## Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Tuner Enhancements: Auto Store
- Station presets: 20
- Antenna: FM fixed pigtail antenna

## Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch)
- Audio Connections: Analogue Audio In (L/R)
- USB: USB host
- Microphone: Microphone socket

## Convenience

- Alarms: CD Alarm, Sleep timer, Radio Alarm, USB alarm
- Clock: On main display
- Indications: DIM mode

## Accessories

- Included accessories: Composite video cable (Y), AC Power Cord
- User Manual: English, Simplified Chinese
- Remote control

## Dimensions

- Gross weight: 5 kg
- Main unit depth: 239 mm
- Main unit height: 177 mm
- Main unit width: 180 mm
- Main speaker dimensions (W x D): 120 x 160 mm
- Main speaker height: 170 mm
- Packaging depth: 231 mm
- Packaging height: 222 mm
- Packaging width: 556 mm
- Net weight: 4.3 kg

## Power

- Power supply: 110-240V, 50/60 Hz

## iPhone compatibility

- Compatible with: iPhone 5

## iPod compatibility

- Compatible with: iPod nano 7th generation, iPod touch 5th generation



Issue date 2014-01-24

Version: 2.0.2

12 NC: 8670 001 05132  
EAN: 69 23410 72232 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)