



Philips
DVD Micro Theater

DivX playback
USB Direct
Compact design

MCD297

Enjoy great movie experience

plus USB Direct playback

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD, WMA-CD and MP3-CD playback! Relax to your fave movies and music. Home entertainment will never be the same again!

Enrich your movie experience

- Play DVD, DivX[®], (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- USB Direct for music and photo playback
- Loudness for bass and treble enhancement
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x15W RMS/2x30W music power
- Autostop cassette deck

Refined in sound and look

- Motorized CD loader for convenience access
- Elegant wood-finished speakers

PHILIPS

Highlights

USB Direct

Simply plug in your USB device on the system and share your stored digital music and photos with your family and friends.

Loudness

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls

you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a

button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.



Specifications

Sound

- Output Power: 2x15W RMS / 2x30W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System, Full range

Video Playback

- Playback Media: DivX, DVD-Video, Picture CD, Video CD/SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Angle, Zoom, Slow Motion, Parental control, PBC, Disc Menu, Fast Backward, Fast Forward, OSD, Resume Playback from Stop
- DVD Region.: 2

Still Picture Playback

- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow with MP3 playback
- Playback Media: CD-R/RW, DVD+R/+RW, Picture CD

Audio Playback

- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Electronic Speed Control
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Tray, Motorised
- ID3-tag support
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level, One-Touch Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store
- RDS: RDS Clock Set, Station Name, Radio Text, Program Type

Connectivity

- Aux in: Line in, 3.5mm
- Other connections: MW Antenna, FM Antenna, Subwoofer out, Digital audio coaxial out
- Video Output - Analog: Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Headphone: 3.5 mm
- Audio Connections: Analogue Audio Out (L/R)
- USB: USB host

Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm, USB alarm
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt
- OSD Languages: Dutch, English, French, German, Italian, Portuguese, Spanish, Swedish, Turkish

Accessories

- Included accessories: FM/MW Antenna, Composite video cable (Y), World Wide Warranty leaflet, AC Power Cord
- Remote control: 40-key with Lithium batteries
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages

Dimensions

- Set dimensions (W x H x D): 152 x 228 x 273 mm
- Main speaker dimensions (W x H x D): 140 x 228 x 212 mm
- Packaging dimensions (W x H x D): 442 x 345 x 275 mm
- Weight incl. Packaging: 7.8 kg

Power

- Power supply: 220-240V, 50Hz



Issue date 2016-10-05

Version: 1.0.5

12 NC: 8670 000 35916
EAN: 87 12581 38604 7

© 2016 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com