



Philips
docking speaker

Lightning connector
for iPod/iPhone



AD315

Enjoy music from your iPhone 5

On your desk or anywhere else, the AD315 docking speaker delivers crystal-clear sound that fills your room. Compatible with iPhone 5 and the latest iPods via the Lightning connector. AC or battery option lets you enjoy your music anywhere.

Crystal clear sound

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Shielding technology to block mobile phone interference

Enjoy your favorite music

- Fast charging and play music via Lightning connector
- Audio-in for portable music playback

Advanced versatility

- Battery or AC power option for music enjoyment anywhere

PHILIPS

Docking speaker
Lightning connector for iPod/iPhone

Specifications

iPhone compatibility

- Compatible with: iPhone 5

iPod compatibility

- Compatible with: iPod nano 7th generation, iPod touch 5th generation

Sound

- Output power: 8 W RMS
- Sound system: stereo
- Volume control: up/down

Connectivity

- Audio in (3.5mm)



Dimensions

- Product dimensions (WxDxH): 300 x 133 x 116 mm
- Packaging dimensions (WxDxH): 387 x 161 x 143 mm
- Product weight: 1.3 kg
- Weight incl. Packaging: 1.65 kg

Power

- Power supply: 100 - 240V AC, 50/60Hz
- Battery type: AA size (LR6)
- Number of batteries: 4
- Battery life time: 8 hr

AD315/12

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Play and charge via Lightning



Enjoy your favorite music while charging your iPod/iPhone via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to work about the battery running out.

Audio-in



The Audio in connectivity allows direct playback of Audio in content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2014-07-24

Version: 1.0.5

12 NC: 8670 001 02281
EAN: 87 12581 68481 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com