

with 30-pin connector for iPod/iPhone 8W

Philips

docking speaker



AD330

Enjoy music from your iPod/iPhone

Built-in with Bass Reflex speakers, this docking system delivers rich, deep bass and powerful sound. Its smart dock lets you charge your iPod/iPhone without the need to remove its protective casing.

Crystal clear sound

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Shielding technology to block mobile phone interference
- 8W RMS total output power

Enjoy your favorite music

- Play and charge your iPod/iPhone simultaneously
- MP3 Link for portable music playback

Advanced versatility

- Dock any iPod/iPhone, even in its case
- Compact design for any space, any lifestyle



Specifications

iPod compatibility

• Compatible with: iPod classic, iPod mini, iPod nano 1st generation, iPod nano 2nd generation, iPod nano 3rd generation, iPod nano 4th generation, iPod nano 5th generation, iPod nano 6th generation, iPod touch, iPod touch 2nd generation, iPod touch 3rd generation, iPod touch 4th generation

iPhone compatibility

• Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S

Sound

- Sound system: stereo
- Volume control: up/down
- Output power: 8 W RMS



iPod [iPhone]

Connectivity

• MP3 Link: 3.5mm stereo line in

Power

• Power supply: 100 - 240V AC, 50/60Hz

Accessories

AC/DC Adaptor

Convenience

· Charging device: iPod, iPhone

Dimensions

- Product dimensions (WxDxH): 260 x 103 x
- 131 mm • Packaging dimensions (WxDxH): 354 x 136 x 167 mm
- Product weight: 1.8 kg
- Weight incl. Packaging: 1.3 kg

AD330/37

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

Dock iPod/iPhone in its case



Smartly designed spring-loaded docking port effortlessly accommodates any iPod or iPhone, without special adaptors. What's more, it works even when most protective cases are on – just dock your iPod or iPhone as it is. Now you can truly have fuss-free enjoyment of your music.



Issue date 2014-08-13

© 2014 Koninklijke Philips N.V. All Rights reserved.

or their respective owners.

Version: 3.1.2

All Rights reserved. Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V.

12 NC: 8670 000 93794 UPC: 6 09585 22864 1

www.philips.com