

Philips 2000 series
Headphones

6 mm drivers/closed-back
Bluetooth®
White

SHB2505WT



Don't stop the music

Anything goes when you have your tunes. These true wireless in-ear headphones give you great sound and up to 20 hours play time with the portable charging case. Double-press the multi-function button to wake your phone's voice assistant.

Ready to go. Up to 20 hours play time.

- 6 mm neodymium acoustic drivers. Great sound, punchy bass
- Mono mode for when you want to leave one ear free
- Portable charging case. Multiple charges in your pocket
- Get up to 20 hours of play time and 14 hours of talk time

Feels good. Looks good.

- Ear-tip covers in small, medium and large — for a perfect fit
- Oval acoustic tube. Comfort and passive noise isolation
- Soft, rubberised wing tips. Secure and comfortable

Easy pairing. Voice control.

- Built-in mic with echo cancellation for clear audio
- Smart pairing. Automatically find your Bluetooth device
- Multi-function button. Easily control music and calls
- A double button-press wakes your phone's voice assistant

PHILIPS

Headphones
6 mm drivers/closed-back Bluetooth®, White

Specifications

Sound

- Acoustic system: Closed
- Diaphragm: PET
- Magnet type: NdFeB
- Frequency response: 20 - 20,000 Hz

Connectivity

- Microphone: Built-in microphone
- Bluetooth version: 5.0
- Bluetooth profiles: AVRCP, A2DP, Hands-free, HFP, HSP
- Maximum range: Up to 10 m

Outer Carton

- Length: 37 cm
- Number of consumer packages: 24
- Width: 27 cm
- Gross weight: 4.2 kg
- Height: 23.5 cm
- GTIN: 1 48 95229 10048 7
- Net weight: 1.104 kg
- Tare weight: 3.096 kg

Convenience

- Call Management: Answer/End Call, Call on Hold, Microphone mute, Reject Call, Switch between 2 calls

Inner Carton

- Length: 17.8 cm
- Number of consumer packages: 3
- Width: 12.8 cm
- Height: 10.4 cm

- Net weight: 0.138 kg
- Gross weight: 0.4 kg
- Tare weight: 0.262 kg
- GTIN: 2 48 95229 10048 4

Power

- Battery type: Lithium-ion
- Music play time: 5+15 hour(s)
- Standby time: 80 hr
- Talk time: 5 hr

Packaging dimensions

- Height: 15 cm
- Packaging type: Carton
- Type of shelf placement: Both
- Width: 9.5 cm
- Depth: 4 cm
- EAN: 48 95229 10048 0
- Gross weight: 0.12 kg
- Net weight: 0.046 kg
- Tare weight: 0.074 kg

Product dimensions

- Height: 6.5 cm
- Width: 4.1 cm
- Depth: 3.6 cm

Accessories

- Quick Start Guide
- USB cable

Design

- Colour: White

SHB2505WT/10

Highlights

Up to 20 hours of play time.

With their portable charging case, these headphones won't let you down. You get up to three hours of play time or talk time on a single charge. If you head out with a fully charged case, you get an additional 9 hours over multiple charges. Just pop the headphones back in the case each time they need charging. A full charge takes 1.5 hours.

Comfortable and secure

You can rock your sounds in real comfort thanks to the snug-fitting, lightweight design. The soft, rubberised wing tips fit securely under the fold of your outer ear. Interchangeable rubber ear-tip covers let you find the perfect in-ear fit — creating a tight seal so you won't miss a beat.

Great sound. Punchy bass.

The 6 mm neodymium acoustic drivers give you great sound and punchy bass. The oval-shaped acoustic tube maximises passive noise isolation. Mono mode gives you the option to leave one ear free for when you want to stay aware of the world around you.

Multi-function button.

Easily control music and calls via the multi-function button. Don't like the current track? Skip it with a long press. Want to reject a call and keep listening? A simple button-press takes care of that. The built-in mic with echo cancellation keeps sound clear when you do want to talk.

Voice assistant

Wake your phone's voice assistant with a double button-press. Ask Siri or Google Assistant to set up your next playlist, call or send messages to friends, check the weather and more.

Smart Bluetooth pairing

Your headphones are ready to pair the instant you take them out of the case. Once they're paired, the headphones remember the last device they were paired with.

Ear-tip covers

Ear-tip covers in small, medium and large — for a perfect fit

Oval acoustic tube

Oval acoustic tube. Comfort and passive noise isolation

Noise and echo cancellation

No more of those annoying echoes when you are talking on the phone. With our acoustic echo cancellation, you always get a clear, undisturbed connection.

Mono mode

Mono mode for when you want to leave one ear free

Portable charging case.

Hit the gym. Then the trail. These true wireless in-ear headphones come with an ultra-portable charging case.



Issue date 2024-03-12

Version: 10.0.2

EAN: 48 95229 10048 0

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com