# **Docking Entertainment System**

AJ301DB

# **Docking Entertainment System**

Meet Philips at the Internet http://www.philips.com

**English** 

Register your product and get support at www.philips.com/welcome

User manual






**PHILIPS** 














# **English**

Congratulations on your purchase and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

## SUPPLIED ACCESSORIES

- 1 X certified AC/DC 18V adaptor
- (Input: 100-240V ~ 50/60Hz 800mA, Output:18V --- 1.6A)
- Docking kit
- 1 X Apple iPod dock (pre-installed with AJ301DB);
- dock adaptors (4 adaptors for different iPod types)
- 1 X ALIX-IN cable

# CONTROLS (See 1)

#### 1 POWER

- switches the system on or to standby mode
  - stops active alarm for 24 hours
- deactivates the sleep function

#### (2) |**44** / **>>**|

# adjust clock/alarm time

- selects previous/next tracks in the dock mode
- fast searches forward/backward in the dock mode
- ③ PRESET 1-5
  - stores recalls and shows radio station
- (4) SLEEP
  - activates the sleep function
  - deactivates the sleep function
- (5) DOCK
  - selects dock mode for Apple iPod
- 6 TUNFR/ AUX
  - selects FM radio mode
  - selects AUX mode
- (7) **M**I
  - starts/pauses playback in the dock mode
  - selects 12 hour or 24 hour mode

- (8) VOL+/-
- adjusts the sound level
- 9 MUTE
- switches playback sound off and on.
- 10 Display - shows clock/alarm times and status of the set

- (1) Dock connector (30 pins)
- connects iPod player 12 ALM 2
  - activates/confirm ALARM 2 time setting
  - displays ALARM 2 time
- switches off ALARM 2 time
- (13) REPEAT ALARM / BRIGHTNESS CONTROL
- switches off the alarm for a 9 minute period
  - changes the brightness of the display illumination
- 14 POWER iack socket for AC/DC 18V adaptor
- 15 Pigtail improves FM reception
- 16 ALM 1
  - activates/confirm ALARM 1 time setting
  - displays ALARM 1 time
- switches off ALARM 1 time
  - 17) TIME SET
  - activates/confirm clock time/date setting
  - (Wake-up mode) DOCK-BUZZER -TUNER - selects alarm mode: dock, buzzer or radio
  - (9) AUX IN jack (3.5 mm)
  - connects to external audio source
  - 20 RESET
  - - clears clock time setting

#### POWER SUPPLY

#### Mains adaptor

1 Connect the mains adaptor to the set's **DC 18V** socket and to the power socket. **Helpful hints:** To avoid damage to the set, use only the adaptor supplied!

The type plate is located on the bottom of the set.

# Remote control Important!

- Before using the remote control, remove the insulation plastic tab as shown in the figure.
- If the remote control does not function correctly or the operating range is reduced, replace the battery with a new (CR2025) type battery.
- 1. Pull the battery tray out as shown in the figure below.
- Replace a new battery according to polarity indication, and fully insert the battery tray back to the original position.



Batteries contains chemical substances, so they should be disposed of properly.

#### CAUTION

High voltage! Do not open. You run the risk of getting an electric shock. The machine does not contain any user-serviceable parts. Modification of the product could result in hazardous radiation of EMC or other unsafe operation.

This product complies with the radio interference requirements of the European Community.

#### SELF-POWERED BACK-UP

The self-powered back-up conveniently allows your preset stations, alarm and clock time settings to be stored for **up to 10 minutes** when there is a power interruption e.g. AC power failure. The complete clock radio and backlight illumination will be switched off.

 If power supply returns after 10 minutes and the display shows: clock time blinking - indicates you need to re-adjust the clock time.

#### BASIC OPERATION

### Switching on the system

- Press POWER.
  - → The system will switch to the last selected source.
- Press TUNER/AUX or DOCK.
  - → The system will switch to the selected source.

# Switching the system to standby mode • In any source mode, press POWER.

# Switching off the volume temporarily

Press **MUTE** on the remote control to stop sound play-back instantly.

- ightharpoonup Playback will continue without sound and the display shows  ${f MUTE}$  .
- To start sound playback you can:
  - press MUTE again;
  - adjust the volume controls;
  - change source.

# Illumination brightness

Press **REPEAT ALARM / BRIGHTNESS CONTROL** once or more.

The brightness of the display can be adjusted:
 Bright → Low → Off → Bright.

#### SETTING THE CLOCK AND DATE

- 1. In any mode, press and hold **TIME SET** until clock digits flashes.
- 2. Press II to select 12 Hours/24 Hours mode.

- Hold down or press ◄◄ / ►► repeatedly to set and adjust the hours.
- 4. Press TIME SET to confirm.
  - → The clock digits for the minutes flash.
- Repeat the steps 3 4 until you complete all the other settings for minutes, year, month and days.

#### TUNER

- 1 Press TUNER/AUX once to switch on the radio (FM only).
  - → Display shows the radio frequency of the last selected waveband. Your preset station is also shown if you are listening to a preset. (See 2)
- 2 Adjust the sound using VOL+/-.
- 3 To select preset stations, press the respective **PRESET** button (1-5).

## **TUNING TO RADIO STATIONS**

- 1 Press and hold I◀◀ / ▶▶I until the frequency in the display starts changing.
- →Display shows "Scrh" during automatic tuning.
- After the system tunes to a station of sufficient reception, display shows its frequency.
   To tune to a weak station, press |◄◄/ ▶►| briefly and repeatedly until an
- To tune to a weak station, press I◄◄ / ►►I briefly and repeatedly until an optimal reception is found.

# To improve reception (FM):

Extend and position the pigtail fully to obtain optimum reception.

#### STORING AND USING PRESET STATIONS

You can store up to 5 FM radio stations in the memory.

- 1 Tune to your desired station (see TUNING TO RADIO STATIONS).
- 2 To store a preset, hold down briefly on a PRESET button 1-5 until you hear a double beep.
- → Display shows the preset number of your station.
- 3 Repeat steps 1 and 2 to store your other stations.
- · You can overwrite a preset station by storing another frequency in its place.
- 4 Press a PRESET button 1-5 (or PRESET ▼ / ▲ on the remote control) to listen to a preset station.
  - → To display clock time, press ► on the set.

# **USING THE ALARM**

#### GENERAL

Two different alarm times can be set. This can be useful when you need to be woken up at a different time e.g. during the week and at the weekend, and you can set different wake-up modes:

- tuner mode.
- buzzer mode. The gentle wake buzzer alarm increases its beep tone frequency within seconds.
- dock mode.

# SETTING THE ALARM TIME (See 3)

- 1 In any mode, press and hold ALM1 or ALM2 for two seconds.
  - → ALM1 / ALM2 icon and the hour digits flash. And the icon for the current alarm mode also flashes.
- 2 Hold down or press ◄◄ / ►► repeatedly to set and adjust the hours.
- 3 Press ALM1 or ALM2 to confirm.
  - → ALM1 / ALM2 icon and the minutes digits flash. And the icon for the current alarm mode also flashes.
- 4 Hold down or press I◄◄ / ►► repeatedly to set and adjust the mintues.
- 5 Press ALM1 or ALM2 to confirm.

### **SETTING THE ALARM MODE**

- 1 Press **POWER** to switch to standby mode.
- 2 Select your choice of alarm mode: either docked player, buzzer, or radio by using the DOCK\*BUZZER \*TUNER slider.
- At the set alarm time, the docked player or radio or buzzer will switch on automatically.

#### Helpful hints:

- If you have selected TUNER alarm mode, make sure you have properly tuned to a station before turning off the set.
- If you have selected DOCK alarm mode, make sure you have docked the compatible player, or the buzzer mode will be selected automatically.
- To check the alarm time setting for ALM1 or ALM2, press ALM1 or ALM2.

#### SWITCHING OFF THE ALARM

There are three ways of switching off the alarm. Unless you cancel the alarm completely, the **24-hour ALARM RESET** will be automatically selected after 59 minutes from the time your alarm first goes off.

## 24 HOUR ALARM RESET

If you want the alarm mode to be stopped immediately but also wish to retain the same alarm setting for the following day:

Press POWER.

#### REPEAT ALARM

This repeats your alarm call at 9 minute intervals.

- During the alarm call, press REPEAT ALARM / BRIGHTNESS CONTROL...
- Display shows ALM1 or ALM2 flashing during a repeat alarm.
- . Repeat if desired (up to a maximum of 6 times).

# **CANCELING THE ALARM COMPLETELY**

• Press ALM 1 or ALM 2 button once or more until ALM1 or ALM2 disappears.

# DOCK (See 4)

By connecting the iPod to your AJ301DB, you can listen to the sound of the docked player through the powerful speakers of the Hi-Fi system.

# COMPATIBLE PORTABLE PLAYER

 Apple iPod models with 30-pin dock connector as follows: Nano 1st /2nd/3rd generation, iPod 5th generation (video), iPod touch and iPod classic.

# **DOCK ADAPTORS**

Before plugging your player in the dock, snap the suitable dock adaptor into the dock to provide a snug fit for the player to be docked.

# Selecting the correct dock adaptor

 4 iPod dock adaptors are included. Each adaptor has indication to match different iPod types.

#### PLAYING APPLE iPod USING AJ301DB

- 1 Snap the compatible iPod into the dock connector.
- 2 Press **DOCK** to switch on the dock mode.
- 3 The connected player will play automatically.

#### Notes:

- In dock mode, if no player is docked for 15 minutes, AJ301DB will come to standby.
- By using the buttons (►II, ◄◄, ►►) and VOLUME) on the AJ301DB and its remote control, the following disc playback features are available: Play/Pause, selecting next/previous track, fast forwarding/rewinding and changing volume.
- The buttons (►11, I◄4, ►►) and VOLUME on the AJ301DB and its remote control can work only with playback of the audio contents stored on the docked player.

#### CHARGING iPod BATTERY USING THE DOCK

By connecting the iPod to your AJ301DB, you can charge the iPod in the standby mode and power-on mode of AJ301DB.

#### SLEEP

This set has a built-in sleep timer, which enables the radio to be automatically switched off after a set period of time. There are five sleep time options.

# Setting and switching off SLEEP

- 1 During playback, set your timer by pressing SLEEP repeatedly until the desired timer option appears.
  - → Selections are follows (time in minute):  $(2 \cdot \square \rightarrow 9 \cdot \square \rightarrow 6 \cdot \square \rightarrow 3 \cdot \square \rightarrow (5 \rightarrow \square F F \rightarrow 1 \cdot 2 \cdot \square)$
- 2 The set will turn off automatically at the selected time.
- 3 To cancel sleep, press either:
  - POWER
  - SLEEP once or more until SLEEP disappears from the display.

#### Reset

Should your set receive external interference e.g. static electricity from carpets, thunderstorms, etc. RESET allows you to clear all previous settings and start up again.

• Use a ballpoint pen to press the RESET hole found on the bottom of the set.

# **CONNECTING AN EXTERNAL DEVICE**

You can listen to the sound of the connected external device through your AJ301DB's speakers.

- 1 Press TUNER/AUX twice to select AUX mode.
- 2 Use the supplied AUX-IN cable to connect AJ301DB's AUX IN jack to an AUDIO OUT or headphone jack on an external equipment (such as CD player, or VCR).

#### **MAINTENANCE & SAFETY**

- Install the unit near the AC outlet and where the AC power plug can be easily reached.
- . The apparatus shall not be exposed to dripping or splashing.
- Do not expose the set to humidity, rain, sand or excessive heat caused by heating equipment or direct sunlight.
- To clean your set, use a soft damp cloth or chamois leather. Do not use cleaning products, which contain benzene, thinner, etc. as these may harm the housing.
- Where the MAINS plug or an appliance coupler is used as the disconnect
- device, the disconnet device shall remain readily operable.
  Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

#### SPECIFICATIONS

Power Consumption	24 W
Output power	
Dimensions (w x h x d)	161 x 191 x 164 (mm)
Weight	1 34 kg

#### TROUBLESHOOTING

If a fault occurs, first check the points listed below before taking the set for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service centre.

WARNING: Under no circumstances should you try to repair the set yourself, as this will invalidate the guarantee. Do not open the set as there is a risk of electric shock!

#### No sound

- Volume not adjusted
- Adjust the volume
  - The set is muted.
  - Press"MUTE" on the remote control to active playback sound.

# Display error / no reaction to any controls

- Electrical malfunction
- . Unplug the power cord, then re-plug.

# Intermittent crackling sound during FM reception

- Weak signal
- · Extend and position the pigtail aerial

# The alarm does not function

- Alarm time/ mode not set
- See SETTING THE ALARM
  - Volume too low for radio

## **Dock operation**

- The menu navigation or photo playback of the docked player cannot be carried out through the buttons on AJ301DB or its remote control.
- The buttons on AJ301DB and its remote control can control playback of audio contents only. To navigate the menu, use the controls on the docked player.
- Some buttons on AJ301DB and its remote control have no function.
- The buttons (►II, I◄◄, ►►I and VOLUME) function only.

ENVIROMENTAL INFORMATION	Notes
All unnecessary packaging material has been omitted. The packaging can be easily separated into three materials: cardboard, polystyrene and plastic.	
Your set consists of materials which can be recycled if disas- sembled by a specialized company. Please observe the local regulations regarding the disposal of packaging, dead batteries	
and old equipment.	
Disposal of your old product	
Your product is designed and manufactured with high quality	
materials and components, which can be recycled and reused.  When this crossed-out wheeled bin symbol is attached to a	
product it means the product is covered by the European Directive 2002/96/EC.	
Please inform yourself about the local separate collection system for electrical and electronic products.	
Please act according to your local rules and do not dispose of your old	
products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.	
Notes for battery disposal Your product contains batteries covered by the European	
Directive 2006/66/EC, which cannot be disposed with normal	
household waste. Please inform yourself about the local rules on separate collection of batteries because correct disposal	
helps to prevent negative consequences for the environmen-	
tal and human health.	