



ENGLISH

Note for mounting

To secure the mounting on wall, concrete wall is required.

Use screws to mount the main unit on the wall

1. Use this sheet as a template. Mark the position where you want to hang the unit on the wall (as shown above) and then drill two 6mm diameter holes.
2. Secure the 2 dowels and 2 screws (both supplied) in the holes respectively. Leave the screws 5mm proud of the wall.
3. Hang the unit on the fastening screws.

简体中文

安装注意事项

要确保在墙上稳固安装，必须是水泥墙。

使用螺钉将主装置安装在墙上

1. 使用此纸张作为模板。标记您要在墙上悬挂装置的位置（如上所示），然后钻两个直径为 6 毫米的孔。
2. 将 2 个销子和 2 枚螺钉（均随附）分别固定在孔中。让螺钉头和墙壁之间保持 5 毫米的间隙。
3. 将装置挂在紧固螺钉上。

* 壁装说明

在墙上标记孔位置处钻孔。