



Philips  
In-Ear Headphones

8.6-mm drivers/semi-closed back  
In-ear

**SHE9100RD**

## Enjoy high-performance precision sound

with solid metal housing

The Philips SHE9100 headphones boast premium drivers and precision-crafted metal housing for detailed yet pure sound. Oval sound tubes and a choice of 3 ear tips ensure comfort and fit.

### Enjoy quality sound

- Sturdy aluminium housing prevents vibration for sound clarity
- Fine-tuned neodymium drivers for high-frequency clarity

### Ultimate wearing comfort

- Silicone caps in choice of three sizes for customised fit
- Curved housing and oval sound tubes for ergonomic comfort

### Always ready to go

- Anti-tangle slider keeps your cables together neatly
- Durable Flexi-grip for strong headphone-to-cable connection

**PHILIPS**

## Highlights

### Aluminium housing



The headphone's housing is crafted from sturdy aluminium, which prevents vibration for the purest sound performance. In addition, it protects the earphones from the wear and tear of everyday use.

### Anti-tangle slider



The smart anti-tangle slider helps you easily keep the two earpiece cables neatly together, simply by gliding it up. No more hassles with tangles or knots!

### Durable Flexi-grip connection

This soft yet durable and flexible connector between the earphone and cable helps protect against potential damage from repeated bending.

### Finely tuned neodymium driver



Neodymium is the ideal material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and higher overall sound quality. It features re-engineered 8.6-mm neodymium drivers that are responsive to high frequencies and ensure pure sound clarity.

### Oval sound tubes

Your in-ear headphones are precisely designed to fit any ear. Their ergonomic oval sound tube and curved architecture ensure an optimised, secure and comfortable fit – always.

### Silicone caps in three sizes



Your in-ear headphones come with a choice of 3 ear caps – from small to large – so you can select the perfect fit for your ears.

## Specifications

### Sound

- Acoustic system: Semi-closed
- Frequency response: 7 - 25,000 Hz
- Diaphragm: Mylar dome
- Impedance: 16 Ohm
- Magnet type: Neodymium
- Type: Dynamic
- Voice coil: Copper
- Speaker diameter: 8.6 mm
- Sensitivity: 108 dB
- Maximum power input: 30 mW

### Connectivity

- Connector: 3.5 mm stereo
- Type of cable: OFC
- Cable Connection: two-parallel, symmetric
- Finishing of connector: Gold-plated
- Cable length: 1.2 m

### Outer Carton

- Length: 38 cm
- Number of consumer packages: 24
- Width: 24,8 cm
- Gross weight: 1,9724 kg
- Height: 24,8 cm
- GTIN: 1 69 25970 70073 0
- Net weight: 0,3000 kg
- Tare weight: 1,6724 kg

### Inner Carton

- Length: 18 cm
- Number of consumer packages: 3
- Width: 11,5 cm
- Height: 10,5 cm
- Net weight: 0,0375 kg
- Gross weight: 0,2003 kg
- Tare weight: 0,1628 kg
- GTIN: 2 69 25970 70073 7

### Packaging dimensions

- Height: 17,5 cm
- Packaging type: Soother
- Type of shelf placement: Soother
- Width: 9,5 cm
- Depth: 3,5 cm
- Number of products included: 1
- EAN: 69 25970 70073 3
- Gross weight: 0,0531 kg
- Net weight: 0,0125 kg
- Tare weight: 0,0406 kg

### Product dimensions

- Height: 8 cm
- Width: 3 cm
- Depth: 3 cm
- Weight: 0,0125 kg

### Design

- Colour: Red



Issue date 2024-03-12

Version: 1.1.7

EAN: 69 25970 70073 3

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)