

Philips Mini Hi-Fi System

FWM197

Enjoy MP3-CD music in rich sound

with USB Direct

Experience uninterrupted enjoyment of your CD/MP3/WMA songs for up to 10 hours on the FWM197. Extend your music pleasure by listening to your tunes at home from your portable player - with USB Direct and MP3 player-in.

Enrich your sound experience

- 120 W RMS total output power
- 2-Way Bass Reflex Speaker System for powerful sound
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings
- · Digital Sound Control for optimised music style settings

Continuous enjoyment of your favourite music

- USB Direct for MP3/WMA music playback
- 10 hours of MP3-CD music
- MP3 Link for portable music playback
- MW/FM digital tuning with presets
- Stereo cassette deck



Highlights

120 W RMS total output power

120 W RMS total output power

2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

Stereo cassette deck

Stereo cassette deck

USB Direct-MP3/WMA

With the USB Direct mode, you can simply select the music on a USB device and playback all your content. All you have to do is plug in your USB device to playback music or export content from the device.

MP3 Link for portable music

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your

favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the Internet, allowing quick and easy audio file transfer.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a

button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Optimal, Jazz, Techno and Rock controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.















Specifications

Sound

- Output power (RMS): 120 W
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control

Loudspeakers

- Main Speaker: 2" tweeter, 2-way, Bass Reflex Speaker System, 5.25" woofer
- Number of Loudspeakers: 2

Audio Playback

- Number of Discs: 1
- · Loader Type: Tray
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Stop, Shuffle
- Disc Playback Modes: Repeat/one/disc/ programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20
- · Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Automatic Stop

Audio Recording

- · Recording Media: Tape
- Tape Recording Enhancement: CD Synchro-Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- · Auto digital tuning
- Auto store
- Number of Pre-set Channels: 40

Convenience

- Alarms: CD Alarm, USB alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Connectivity

- Aux in: 3.5 mm stereo
- USB: USB host
- Audio Connections: RCA Aux in

Accessories

- Included accessories: Remote Control, Guarantee booklet, Quick Use Guide
- User Manual: 16 Languages

Dimensions

- Set dimensions (W x H x D): 220 x 292 x 285 mm
- Packaging dimensions (W x H x D): 730 x 348 x 275 mm
- Weight incl. Packaging: 11.2 kg

Power

- Power supply: 200-240 V, 50 Hz
- Standby power consumption: < 2 W



Issue date 2011-12-13

Version: 1.0.2

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 58902 EAN: 87 12581 51992 6

www.philips.com