

Philips
Mini Hi-Fi System

MP3

FWM35



MP3 playback with rich sound experience

Fulfill all your music needs with FWM35 MP3 Mini Hi-Fi System, which delivers superbly rich sound. Plus the freedom to savor 30 hours of your favorite MP3-CD music and intuitive ease-of-use make this set a joy to use!

Enrich your sound experience

- 2x30W RMS/2x60W Music Power
- 2-Way Bass Reflex Speaker System for powerful sound

Longer listening, greater enjoyment

- Playback 30 hours of MP3-CD music
- 3-disc changer for WMA/MP3-CD music playback
- Dual logic tape deck with auto replay

Personalised sound settings

- 3-step Dynamic Bass Boost
- Digital Sound Control for optimized music style settings

PHILIPS
sense and simplicity

Specifications

Sound

- **Output Power:** 2x30W RMS / 2x60W music power
- **Sound Enhancement:** Digital Sound Control 4 modes, Dynamic Bass Boost 3 steps

Loudspeakers

- **Main Speaker:** 2 way, 2" tweeter, 5.25" woofer, Bass Reflex Speaker System
- **Number of Loudspeakers:** 2

Audio Playback

- **Cassette Deck Technology:** Full Logical
- **Cassette Playback Modes:** Fast wind / rewind
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD
- **Disc Playback Modes:** 99-Track Programmable, Repeat/one/disk/program, Shuffle Play
- **Loader Type:** 3 CD Carousel
- **Number of decks:** 2
- **Number of Discs:** 3

Audio Recording

- **Tape Recording Enhancement:** Automatic Recording Level, CD Synchro Start Recording

Tuner/Reception/Transmission

- Auto digital tuning
- **RDS:** News, Program Type, Radio Text, RDS Clock Set, Station Name
- **Station presets:** 40
- **Tuner Bands:** FM, MW
- **Tuner Enhancements:** Auto Store, Easy Set (Plug

& Play)

Connectivity

- **Aux in:** Line in
- **Headphone:** 3.5 mm
- **Other connections:** FM Antenna, MW Antenna

Convenience

- **Alarms:** CD Alarm, Radio Alarm, Sleep timer
- **Clock:** On main display
- **Display Type:** FTD
- **Eco Power Standby:** 1 watt
- **Indications:** DIM mode

Accessories

- **Included Accessories:** AC Power Cord, FM/MW Antenna
- **Remote control:** 21 key

Dimensions

- **Set dimensions (W x H x D):**
265 x 310 x 367 mm
- **Main speaker dimensions (W x H x D):**
248 x 310 x 195 mm
- **Packaging dimensions (W x H x D):**
611 x 411 x 440 mm
- **Weight incl. Packaging:** 15.6 kg

Power

- **Power supply:** 200-240 V, 50Hz
- **Standby power consumption:** <1W

Product highlights

2x30W RMS/2x60W Music Power

2-Way Bass Reflex System

30 hours of MP3-CD music

3-disc changer for WMA/MP3-CD

Dual logic tape deck

3-step Dynamic Bass Boost

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2007-12-06

Version: 5.0

12 NC: 9073 100 12445
EAN: 87 10895 86624 8

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com