



User Manual Addendum

1. Bluetooth pairing

! *Note: This product with Play-Fi CAP version 506.3.0.063 or 506.3.0.077 requires Play-fi/Wi-fi connection to be set up and functioning before*

Bluetooth pairing is allowed to operate. Please follow the instructions in the section "Connect to Wi-Fi (Wireless Operation)" in user manual to complete Play-fi/Wi-fi setup when the product is used for the first time.

Bluetooth pairing procedure:

1. Switch the device to Bluetooth source.
2. Press Source button  on remote control for more than 3 sec. Or Press setting menu  to select BT PAIR and press > to start.
3. Find the device with name XXXXX-BT in available device list in your phone/tablet (XXXXX is the name chosen during Play-Fi setup).
4. Select XXXXX-BT and wait for Bluetooth connection to be made. Normally, complete in 1-2 seconds.