

Philips docking speaker with Bluetooth®

# Bluetooth®

with Lightning connector for iPod/iPhone 10W, rechargeable battery



DS7880

# Designed to go places

Compatible with iPhone 5 and the latest iPods through the Lightning connector, DS7880 docking speaker delivers powerful sound and ensures wireless streaming. Designed for travel, it also comes with rechargeable battery and a carrying pouch.

## Sound that blows you away

- wOOx technology for rich yet precise bass without distortion
- DBB to preserve low tones for deep bass at any volume level
- · Shielding technology to block mobile phone interference
- 10W RMS total output power

## **Advanced versatility**

- Wireless music streaming via Bluetooth
- · Fast charging and play music via Lightning connector

#### Made to go places

- Built-in rechargeable Li-ion battery for long music playback
- Carrying pouch included

## Truly portable and versatile

- Elegant, slim and compact design to fit into any briefcase
- Audio-in for easy portable music playback



#### Docking speaker with Bluetooth® Bluetooth® with Lightning connector, for iPod/iPhone, 10W, rechargeable battery

# Highlights

#### Play and charge via Lightning



Enjoy your favorite music while charging your iPod/ iPhone via the new Lightning connector! Just dock it directly on the speaker to play your hand-picked tunes in superb sound. It also charges your device quickly while playing, so you don't have to work about the battery running out.

#### wOOx technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.





## **Dynamic Bass Boost (DBB)**



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even

#### AUDIO-IN (3.5mm)



Make one easy connection and enjoy all your music from portable devices and computers. Simply plug your device to the AUDIO-IN (3.5 mm) port on your Philips set. With computers, the connection is typically made from the headset output. Once linked, you can enjoy your entire music collection directly, on a set of superior speakers. Philips simply delivers better sound.



when you turn down the volume.

# iPhone compatibility

Compatible with: iPhone 5

DS7880/37

# iPod compatibility

· Compatible with: iPod nano 7th generation, iPod touch 5th generation

#### Connectivity

- Bluetooth profiles: A2DP
- Bluetooth range: line of sight, 10M or 30FT

**Specifications** 

- Bluetooth version: 2.1
- Audio in (3.5mm)

#### Sound

- Output power (RMS): 10W
- Sound Enhancement: Dynamic Bass Boost
- Sound System: Stereo
- · Volume Control: Volume Control up/down

# Loudspeakers

Neodynium magnet system

#### Power

- Power supply: 100-240VAC, 50/60Hz
- Battery type: Li-ion (built-in)
- Operating time on battery: up to 8 hr

#### **Dimensions**

- Product dimensions (WxDxH): 381 x 44 x 107 mm
- Packaging dimensions (WxDxH): 405 x 82 x 150 mm
- Product weight: 0.58 kg
- Weight incl. Packaging: 1.16 kg



Issue date 2014-08-14

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 1.0.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 03622 UPC: 6 09585 23414 7

www.philips.com

AUDIO **iPod iPhone**