



Philips
PhotoFrame

20.3cm/8" LCD

4:3 frame ratio

8FF3FPW



Share your memories

Exclusive 08 China design

See, share, organize and relive your memories with Philips stylish imperial red and gold PhotoFrame™ design, the easiest way to share your memories by displaying your digital photos in stunning quality.

Top quality display for print-like pictures

- High pixel density for sharp and detailed photo display
- imagen for sharp and vibrant color
- 4:3 aspect ratio for optimal distortion-free display
- Add new glow to old memories with RadiantColor
- SmartContrast: For incredible rich black details

Easily display and manage your digital photos

- Have fun with collages: display mutiple photos in one view
- Play slideshows, single photo, thumbnails or show clock
- View photos directly from memory cards - no PC required
- View USB flash drive photos without a PC

Simple intuitive operation and great convenience

- Intuitive UI, 5-way-keypad for easy navigation and operation

Green design

- Auto on/off display at pre-set times for power saving

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 130° (H) / 110° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Brightness: 250 cd/m²
- Panel resolution: 800 x 600
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- USB: USB flash drive
- Memory Card Types: Compact Flash type I, Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo, Memory Stick Pro Duo

Convenience

- Card Reader: Built-in (2x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Sepia
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Gray, Ambient color, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Beep on/off, Set time and date, Clock display enable/disable, Alarm
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory

- Plug & Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Russian, Simplified Chinese, Japanese

Accessories

- Included accessories: AC-DC Adapter, USB cable, Stand, Quick start guide, User Manual

Dimensions

- Set dimensions with stand (W x H x D): 244.6 x 167.4 x 121.1 mm
- Weight: 0.494 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power consumption: 6.3 W
- Power mode supported: AC powered

Packaging dimensions

- Packaging dimensions (W x H x D): 30 x 29 x 9 cm
- Nett weight: 0.91 kg
- Gross weight: 1.31 kg
- Tare weight: 0.4 kg
- EAN: 87 12581 43690 2
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 55.6 x 31.6 x 31.8 cm
- Nett weight: 5.46 kg
- Gross weight: 8.9 kg
- Tare weight: 3.44 kg
- GTIN: 1 87 12581 43690 9
- Number of consumer packagings: 6

Highlights

imagen technology

imagen is exclusive Philips photo enhancement technology that automatically analyzes your photos to correct color and adjust for optimal contrast: imagen separates colors to avoid "crosstalk" adjusts brightness distribution for great visual contrast and corrects Gamma for color accuracy.

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than the screen size.

Multiple viewing modes

Flexible display modes give you the freedom to display your photos one image at a time, in thumbnail mode for quick, easy searches, or to create a slideshow of your most treasured photos.

Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on USB flash drive.

Auto on/off display

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.



Issue date 2013-01-31

Version: 4.0.3

12 NC: 8670 000 41553
EAN: 87 12581 43690 2

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com