

Philips
DVD player/recorder with
i.LINK digital input



DVDR615

Experience the magic of DVD Recording!

Now you can copy your favorite camcorder tapes for life on DVD, in perfect digital picture and sound quality thanks to i.LINK.

Record your favorite TV programs on DVD

- i.LINK digital input for perfect digital camcorder copies
- 2.0 Dolby Digital Encoding for quality audio recording
- Record up to 6 hours on a single layer DVD+R/RW or DVD-R/RW

Share your favorite recordings

- Index Picture Screen is a DVD menu created on a DVD disc
- Your DVDs will play on existing DVD players and drives
- Always compatible recordings: with DVD+R/RW discs

Enjoy your favorite movies and music

- Progressive Scan component video for optimized image quality
- Plays JPEG and MP3 files from Disc/HDD
- Coaxial connection ensures a reliable digital output

PHILIPS

Specifications

Picture/Display

- Aspect ratio: 4:3, 16:9
- D/A converter: 10 bit, 54 MHz
- A/D converter: 10 bit, 54 MHz

Sound

- D/A converter: 24 bit, 96 kHz
- A/D converter: 24 bit, 96 kHz
- Signal to noise ratio: 95
- Distortion and Noise (1kHz): 85 dB
- Crosstalk (1kHz): 95 dB
- Dynamic Range (1kHz): 85 dB

Video Playback

- Playback Media: CD-R/CD-RW, DVD, DVD+RW, DVD-RW (Video mode), DVD-R, DVD-Video, MP3-CD, Video CD/SVCD
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

Video Recording

- Recording system: NTSC
- Compression formats: MPEG2
- Recording enhancements: Append, Chapter Marker Insertion, Divide, Erase, Manual Chapter Marking, One Touch Record (OTR), Station ID Recording
- Recording Modes: M1: 60 minutes, M2: 120 minutes, M2x: 150 minutes, M3: 180 minutes, M4: 240 minutes, M6: 360 minutes, M8: 480 minutes
- Audio compression: Dolby Digital

Audio Playback

- Playback Media: MP3-CD, CD, CD-R, CD-RW
- Compression format: Dolby Digital, DTS, MP3, MPEG2 Multichannel, PCM
- MP3 bit rates: 32 - 256 kbps

Still Picture Playback

- Playback Media: Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Create albums, Edit photos (colors, filters), Flip photos, Rotate
- Slide show: 3 speeds
- Thumbnail support: EXIF format

Storage Media

- Recording media: DVD+R, DVD+RW

Tuner/Reception/Transmission

- Aerial Input: 75 ohm coaxial (IEC75)
- TV system: PAL

Connectivity

- Front / Side connections: i.LINK DV in (IEEE1394, 4-pin), S-video in, Video in, Audio L/R in
- Other connections: Analog audio Left/Right in, Analog audio Left/Right out 2x, Component Video (YPbPr) input, Component Video out Progressive, Composite video (CVBS) input, Composite video (CVBS) out, Digital coaxial out, RF antenna in / TV out, S-Video in, S-Video out

Convenience

- Programming/Timer Enhancements: Daily/Weekly Repeat Program, Manual Timer, One Touch Recording
- Child Protection: Parental Control
- Ease of Installation: Autoinstall, Sorting

Power

- Power supply: 50Hz, 220-240V
- Power consumption: 27 W
- Standby power consumption: < 4 W

Accessories

- Included accessories: AC Power Cord, Audio/Video cable, Blank DVD+RW Disc, Coax RF antenna cable, Guarantee booklet, Quick start guide, User Manual, Remote Control, Batteries for remote control

Dimensions

- Set dimensions (W x H x D): 435 x 285 x 65 mm
- Set weight: 3.5 kg
- Packaging dimensions (W x H x D): 518 x 159 x 383 mm
- Weight incl. Packaging: 5.0 kg

Highlights

i.LINK digital input

Also known as IEEE 1394 and FireWire, i.Link carries all audio and video signals via a single cable digitally, with no loss in picture and sound quality. With i.Link digital video input, you can copy your home videos in their original digital picture quality.

2.0 Dolby Digital Encoding

Dolby Digital is an advanced digital audio encoding technology that is used on all DVD-Video discs. Philips DVD Recorders store audio in the same format, so it is fully compatible with any DVD player. The quality surpasses that of analog video recorder.

6 hours video recording

The 6-hour record mode available on specific DVD recorder models lets you record up to six hours of video on a single layer DVD+R/RW and DVD-R/RW discs.

Index Picture Screen

The Index Picture Screen is a DVD menu created on every DVD+R/RW disc that is also accessible on regular DVD players. It gives you an instant overview and easy access, so you can directly see what's on the disc and navigate to the recording you want to watch.

Always compatible recordings

Always compatible recordings: with DVD+R/RW discs

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Plays JPEG and MP3 files

Plays JPEG and MP3 files from Disc/HDD

Coaxial digital audio output

Coaxial connection ensures a reliable digital output



Issue date 2014-02-07

Version: 3.0.5

12 NC: 8622 810 11641
EAN: 87 10895 80015 0

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com