

PHILIPS

USB power bank

20,000 mAh

3 USB charging ports

QC 3.0 and PD 3.0

PPS

DLP7721C



Powerful power bank

with a portable back-up power pack

Large 20,000mAh capacity with safe Li-polymer battery. No more hassle when your mobile phone is out of battery. Fast-charge your device with USB-C PD 3.0 Max 20 W or USB-A port with QC 3.0 Max 18 W output.

Superior Charging Design

- Smart protection against overheating, overvoltage and overcurrent
- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- 3 USB ports charge three devices simultaneously
- USB-A with QC fast charging
- USB-C PD 20 W charging port

Confirm operation at a glance

- LED power-indicator light

Portable power

- Works anywhere - great when you're not near a power source

Highlights

USB-C PD 20 W charging port.

Equipped with USB-C (Power Delivery) PD 20 W fast charging port.

USB-A with QC fast charging

Quick Charge (QC) fast-charging technology delivers faster charging by increasing voltage and current. It uses the Quick Charge protocol to optimise charging speeds for compatible devices, reducing charge times.

50% charge in 30 min

Fast charging - charge your mobile phone from 0 to 50% in 30 minutes time.



Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

Smart Protection

Smart protection against overheating, overvoltage and overcurrent

LED power-indicator light

The discreet LED light glows softly to let you know at a glance that the unit is charged.

Specifications

Design and finishing

Materials: PC + ABS

Outer Carton

Length: 34 cm

Number of consumer packages: 18

Length: 13.4 inch

Width: 24 cm

Height: 22.5 cm

GTIN: 1 48 95229 13553 3

Width: 9.4 inch

Height: 8.9 inch

Inner Carton

Length: 22 cm

Number of consumer packages: 6

Length: 8.7 inch

Width: 10.7 cm

Height: 20.5 cm

Width: 4.2 inch

Height: 8.1 inch

GTIN: 2 48 95229 13553 0

Compatibility

Works with the following: USB-charged devices

Power

Battery Capacity: 20,000 mAh 74 Wh

Power input: Type-C 5 V/3 A, MicroUSB 5 V/2 A

Output: USB-C Max 20W USB-A Max 18 W

Packaging dimensions

Height: 17 cm

Type of shelf placement: Both

Width: 9.5 cm

Depth: 3.5 cm

Height: 6.7 inch

Number of products included: 1

EAN: 48 95229 13553 6

Width: 3.7 inch

Depth: 1.4 inch

Product dimensions

Height: 13.6 cm

Width: 6.8 cm

Depth: 2.75 cm

Width: 2.7 inch

Height: 5.4 inch

Depth: 1.1 inch

Weight: 0.355 kg

Weight: 0.783 lb

Accessories

Cables: USB-C charging cable

User Manual: User Manual

